




ORIGINAL INSTRUCTION MANUAL

















DEAR CUSTOMER,





Thank you for choosing our product. Please read this manual carefully before assembling or using the product, to avoid damage caused by improper use. If the product is passed on to third parties, this manual has to be passed on along with the product. For any question don't hesitate to contact us



PARTS LIST

1	1×	2	1×	3	2×
					
4	4×	5	4×	6	2×
					
7	1×	8	8×	9	8×
					
10	2×	11	2×	12	2×
					
13	4×	14	4×	15	2×
					


Hardware LIST

A 4×  M8×50mm	B 12×  M8×20mm	C 20×  M6×15mm
D 12×  M6×12mm	E 12×  M6	F 1×  M6
G 1×  M8	H 1×  M6	I 8×  M8
J 1×  M8		

ASSEMBLY


Before your installation, please make sure that you have all the parts listed on the manual. If you find something missing, stop installing and contact your supplier immediately.


1




	C X4PCS
	H X1PCS
	B X4PCS
	G X1PCS

2




	A X4PCS
	G X1PCS

3



4


	8 X8PCS
	9 X8PCS
	C X16PCS
	H X1PCS




5

	B X8PCS
	G X1PCS

5




6




7

	①X8PCS
	①JX1PCS




8



9

	15X2PCS
	DX12PCS
	EX12PCS
	HX1PCS
	FX1PCS



10

