




MANUAL INSTRUCTION

6' x 8' Double-roof BBQ Gazebo

WS24110103




Illuminating Outdoor Living


part 1: Precautions and preparations..... 3-5

part 2: Parts & Tools 6-10

part 3 11-23



part 4 24-31



part 5 32-43



part 7: Help Center 44



At Solumia, we transform outdoor spaces through exceptional design and superior craftsmanship.

As a leading patio furniture brand, we combine innovative designs with premium manufacturing to create outdoor living products that exceed expectations.

We believe in creating more than just furniture – we deliver lifestyle solutions that help you make the most of your outdoor space.

Through continuous innovation and customer feedback, we constantly evolve to meet and anticipate your needs. Choose Solumia to illuminating your outdoor living experience.



WARNING

- 1. Four or more people are required for assembly.**
- 2. A ladder and electric drill may be necessary.**
- 3. Do not erect the structure in heavy winds or inclement weather.**
- 4. Do not use candles, matches, or any open flames near the tent.**
- 5. To better align the screws for practical situations, do not fully tighten screws initially.**
- 6. Professional installation is highly recommended.**


WARNING

- In case of strong winds, do not remain under or inside the gazebo.
- Do not stay under the gazebo during heavy snowfall.
- For safety, secure the posts to the ground using expansion bolts.
- During windy conditions, ensure all fence panels and netting are properly tightened to prevent wind damage.
- In severe weather, you may secure additional stability by attaching ropes to the four corners of the gazebo.
- Remove accumulated snow from the roof promptly during snowfall.
- Ensure all screws are properly tightened before use.
- Check and retighten all screws, buckles and straps every 90 days.
- During assembly, keep all screws loosely fastened until installation is complete, then fully tighten.
- Do not use or store near open flames or flammable chemicals.
- Exercise caution - some components have sharp edges and should be handled with protective gloves.
- If any parts become missing, broken, damaged or worn, stop using the product until repairs are made using factory authorized replacement parts.
- Installing the product in a way that does not follow manufacturer's instructions may void the warranty coverage.


WARNING

WARNING: This product can expose you to Carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

PARTS



A1 X 2




D2 X 2



A2 X 2




E X 4



A3 X 4




E1 X 4




B X 4




E2 X 4




C X 4



F1 X 2




D1 X 2




F2 X 2


PARTS



G1 X 2




J1 X 2




G2 X 4




K1 X 2




G3 X 2




K2 X 2



G4 X 2




K3 X 4




H X 4



L X 4




J X 4




M X 2


PARTS




N X 1



Q3 X 4




N1 X 4



R X 4



P1 X 2




S X 1



P2 X 2



T X 1



Q1 X 2



U1 X 2



Q2 X 4



U2 X 2

PARTS




U3 X 2




V1 X 2




V2 X 2




W1 X 2




W2 X 4




W3 X 4



W4 X 4





W5 X 4




X X 4


HARDWARE




SPARE HARDWARE




Part 3




1





A1 X 2



A3 X 2



AA X 4



A3


A1



1


A3

A1




x2


2




A2 X 2



A3 X 2



AA X 4



A3




A2




A3

1







A2







x2

3






x4


4




5





x2



6





EE X 16







x2

7



8





G1 X 2




G2 X 4



G3 X 2




G4 X 2






AA X 12





x2






10




11





12




Part 4




13






14



L X 4




AA X 16




15





J1 X 2



M X 2









AA X 4




x2




16












AA X 4







Part 5





20



Q1 X 2




AA X 4




21





Q2 X 4



Q3 X 4




AA X 16







R X 4



BB X 4



CC X 4








S X 1






T X 1







FF X 2






x2
















W1 X 2






AA X 8












30



Grassy surfaces



HELP CENTER

QUALITY COMMITMENT & RETURN POLICY

We stand confidently behind our furniture quality. If you experience any concerns with your purchase, please contact our customer service team before initiating a return. We're committed to finding a solution that ensures your satisfaction.

Important: Please retain original packaging until assembly is complete and you're satisfied with the product quality.

Return Period:

- 30-day return window from purchase date
- One-year warranty on all purchases

Return Shipping Coverage:

We Cover Shipping When:

1. Manufacturing defects are present (e.g., damaged materials, misaligned parts)
2. Items arrive damaged during transit
3. Incorrect items shipped due to warehouse error
4. Partial order loss during shipping

Customer Covers Shipping When:

1. Change of mind after delivery
2. Product no longer needed
3. Ordering mistake
4. Failed cancellation attempts after delivery

Note: Our customer service team is here to help find the best solution for your situation. Please contact us to discuss your concerns before proceeding with a return.

All returns require photo documentation for processing.

Contact us at

✉ services@vonssen.com

RETURN REQUEST GUIDELINES

Requirements for Full Refund:

1. Item Condition

- Must be brand new/unused
- Photos required before and after packaging

2. Packaging

- All accessories and parts must be included
- Use original packaging materials
- Secure packing required

Refund Process:

- Refund issued after items arrive at our warehouse
- Incomplete/improper returns may result in partial refund

Beyond Return Period:

If your product shows damage or defects outside the standard return window, please email us.

We value your satisfaction and will work with you to find an appropriate solution.

Note: Our goal is your complete satisfaction as our customer.