

Sprout Mini Kitchen (WCF58)

Assembly Instruction

Please follow this instruction to avoid assembly errors.

For customer service, please contact **E-mail: shop@robud.com**



98.1WCF58.150



WARNING:

- CHOKING HAZARD-Small parts. Not suitable for children under 3 years.
- Toys intended to be assembled by an adult. Children should use the product under adult's guidance.
- After opening the package, please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation
- The instruction must be retained since it contains important information.

MAINTENANCE:

- Please keep the product away from fire, substances flammable and humid environments to prevent damage.
- Please keep the product away from water, and don't put liquid in the pot sets.
- Please clean the product with dry soft cloth, don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.

Assembly Tips





Assembly time: 2-2.5 hours





Recommended Tools:

(Please prepare them by yourself.)



- Avoid overtightening screws during assembly.
- Screws should be fully tightened once.
- Arrange all accessories on a hard, flat surface for assembly.
- Follow the instructions step by step.



If you feel hard to assemble the toy or there is any other problem that makes you feel unhappy with the product, please contact us shop@robud.com. We are glad to do our best to solve your problem and provide a solution to your satisfaction.

Helpful Hints and Tips

Icon Illustration:



Special attention in assembly

1 Step 1




Remove the plastic film on surface

2 Step 2




Perspective conversion



Notice:





















When assembling the door stop, hold the screw with the screwdriver first and then adjust the screw to the position shown on the left.



















Notice:

The white plastic part is correctly assembled during production.
If the screws are not in position due to transportation, use a slotted screwdriver to adjust.








Product Parts

1	2	3	4
			
x1	x1	x1	x1
5	6	7	8
			
x1	x1	x1	x1
9	10	11	12
			
x1	x1	x1	x1
13	14	15	16
			
x1	x1	x1	x1
17	18	19	20
			
x1	x1	x1	x2

Product Part&Hardware

21 	22 	23 	24 
x1	x1	x1	x3
25 	26 	27 	28 
x1	x1	x1	x1
29 	30 	31 	32 
x1	x4	x4	x1
33 	34 	35 	36  M3x8mm
x6	x2	x4	x8
37  M3x8mm	38  M4x8mm	39  M3x12mm	40  M4x20mm
x4	x6	x6	x16

Product Part&Hardware&Accessories

41  M4x35mm	42 	43 	44 
x40	x1	x1	x1
45 	46 	47 	48 
x4	x1	x2	x1
49 	50 		
x1	x1		

Assembly Instruction

1

41 x4

41

M4x35mm

8PCS

3

30 x4

41 x4

2

39

M3x12mm

2PCS

32

39 x2

6

Assembly Instruction

3

41

M4x35mm

2PCS

6

3

41x2

41

M4x35mm

2PCS

4

36

M3x8mm

2PCS

8

36x2

35

36

M3x8mm

2PCS

5

41

M4x35mm

2PCS

41x2

8

41

M4x35mm

2PCS

6

40

M4x20mm

2PCS

40x2

15

24

40

M4x20mm

2PCS


! Notice:

Pay attention to the direction of the board.

Assembly Instruction

7


Diagram showing the side panel being attached to the base unit. An arrow indicates the direction of movement. The side panel is labeled 15.



8

Diagram showing the top panel being attached to the side panel. Two screws (40) are used to secure the top panel. The top panel is labeled 13, and the side panel is labeled 24.

40 M4x20mm 2PCS



9


Diagram showing the front panel being attached to the side panel. Two screws (36) are used to secure the front panel. The front panel is labeled 5, and the side panel is labeled 13.

36 M3x8mm 4PCS



10

Diagram showing the back panel being attached to the side panel. An arrow indicates the direction of movement. The back panel is labeled 5, and the side panel is labeled 13.



Assembly Instruction

11

41

M4x35mm

4PCS

41x2

41x2

41x2

41x2

41x2

41x2

12

39

M3x12mm

2PCS

39x2

39x2

39x2

39x2

39x2

13

40

M4x20mm

2PCS

40x2

40x2

40x2

40x2

40x2

14

37

M3x8mm

4PCS

37x4

37x4

37x4

37x4

37x4

Assembly Instruction

15

39



2PCS

M3x12mm

27




39x2



27


7







16

12




7





17


40



2PCS

M4x20mm

23



40x2




4

4





18



4



