




INSTRUCTION MANUAL

NOTES


- You need a helper to finish the installation.
- Don't over-tighten the screws until all the parts are in place. Failure to follow the instructions may cause misalignment of the screws.
- DO NOT let children climb the product.
- To avoid suffocation danger, keep small parts and package materials away from children.
- Adult assembly required. Keep children away during the installation.
- Children should not use it without parents' supervision.
- You could use "corner guard" to protect children from getting hurt by the edges.
- If any parts were missing, broken or wrong delivered, contact us immediately



To better adapt to your home layout and environment, we provide 2 installation methods for you to choose from. There may be extra screw holes after installation, please do not worry.


INSTALLATION METHOD 1

Note: Installation method 1 is on the 6 to 15 page.




INSTALLATION METHOD 2

Note: Installation method 2 is on the 16 to 25 page.



PARTS LIST

Parts •




PARTS LIST


Parts

13


x1

**14**


x1

**15**


x1

**16**

x1

**17**


x1

**18**

x4

**19**

x1



Hardware

A

x9+1



M6 X 40 mm

B


x27+2



M6 X 28 mm

C







x2



M6 X 20 mm


PARTS LIST

Hardware

D x11 +1  M6 X 12 mm	E x12+1  M5 X 40 mm	F x2  M3.5 X 14 mm
G x1  M4X8mm	H x8  M8X18mm	I x1 
J x2  Φ6*30mm	K x1  K-1 K-2	L x1 
M x6  φ12 mm		

Note: Extra parts will be presented as spare use.


INSTALLATION METHOD 1




INSTALLATION STEPS

Note: Don't over-tighten the screws until all the parts are in place.

Step1




Step2




INSTALLATION STEPS

Step3




Step4



INSTALLATION STEPS


Step5

Note: The direction of the metal piece on the guide rail part 7 is consistent with that of the guide rail part 8.



Step6


Note: Please tighten all the screws firmly in this step.



INSTALLATION STEPS

Step7 •


Note: Please tighten all the screws firmly in this step.



B 4PCS

Step8 •

Note: Please tighten all the screws firmly in this step.




F 2PCS

I 1PC

INSTALLATION STEPS

Step9 •


Note: Please tighten all the screws firmly in this step.



B 2PCS

Step10 •


Note: Please tighten all the screws firmly in this step.




B 2PCS

INSTALLATION STEPS

Step 11




Step 12




INSTALLATION STEPS

Step13 •




Step14 •




INSTALLATION STEPS

Step15 •




Step16 •




INSTALLATION STEPS

Step17 •




Step18 •




INSTALLATION STEPS

Step19 •

Note: Finally, plug K into power supply, K can be adjusted by K-2.




Step20 •




M 6PCS


INSTALLATION METHOD 2



Step1 •




Step2 •




INSTALLATION STEPS

Step3




Step4

Note: The metal piece on Part 7 should face back.




INSTALLATION STEPS

Step5 •



Step6 •


Note: Please tighten all the screws firmly in this step.



INSTALLATION STEPS

Step7 •


Note: Please tighten all the screws firmly in this step.



B 4PCS

Step8 •

Note: Please tighten all the screws firmly in this step.




F 2PCS

I 1PC

INSTALLATION STEPS

Step9 •


Note: Please tighten all the screws firmly in this step.



B 2PCS

Step10 •


Note: Please tighten all the screws firmly in this step.




B 2PCS

INSTALLATION STEPS

Step 11 •




Step 12 •




INSTALLATION STEPS

Step 13




Step 14




INSTALLATION STEPS

Step15




Step16




INSTALLATION STEPS

Step17 •




Step18 •




INSTALLATION STEPS

Step19 •


Note: Finally, plug K into power supply, K can be adjusted by K-2.



Step20 •



REMOTE CONTROL INSTRUCTION



Specification

Dynamic mode	22 modes
Static Color	20 colors
PWM Grade	256 levels
Brightness Grade	5 levels
Speed Grade	10 levels
Demo mode	Yes
Direct Color Select	Yes
Output Color Switchable	Yes, 6 options
Working Voltage	DC 5~24V
Output Current	3x4A peak, 3x2A constant
Remote frequency	433.92MHz

WARNINGS

Seller does not assume any and all responsibility or liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect instruction, improper use, inadequate maintenance, or neglect of this product.