


BAR STOOL

INSTALLATION INSTRUCTION


Parts List							
	 Ax1	 Bx1	Cx1	 Ex4	 Fx1	 Gx4	 Ix1
			 Dx1			 Hx4	 Jx1
							 Kx1

STEP1




NOTE: Please don't tighten the rails Ⓓ at step1.

STEP2



Tighten all the screws Ⓗ and nuts Ⓖ.

STEP3



STEP4

