


# **ASSEMBLY INSTRUCTION**



**table of contents**




|              |       |
|--------------|-------|
| introduction | 2     |
| hardware     | 4     |
| parts list   | 5     |
| assembly     | 6 - 8 |

# hardware

---

(A) x 8

5/16" x 50mm  
round hex screw




(B) x 8

Φ 8mm lock washer



(C) x 8


Φ 22mm flat washer



---

(D) x 1



5mm Ball end  
Hex wrench



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------|----------|
|------|-------------|----------|


|   |                 |   |
|---|-----------------|---|
| ① | chair cushion   | 1 |
| ② | right front leg | 1 |
| ③ | left front leg  | 1 |
| ④ | right back leg  | 1 |
| ⑤ | left back leg   | 1 |

Chair legs and hardware are under the seat.  
Please tear open the Velcro to retrieve the parts.




# step 1.

1




2



(A) x 4

5/16" x 50mm  
round hex screw




(B) x 4

Φ 8mm lock washer




(C) x 4

Φ 22mm flat washer




(D) x 1

5mm Ball end  
Hex wrench




Please do not assemble with power tools

step 2.



(A) x 4

5/16" x 50mm  
round hex screw




(B) x 4

Φ 8mm lock washer




(C) x 4

Φ 22mm flat washer



(D) x 1

5mm Ball end  
Hex wrench




Please do not assemble with power tools

## step 3.


.....

A friendly reminder from us:

Please keep the Allen wrench.



After a period of time, there may be a chance the KD furniture may become loose, please use an Allen wrench to tighten the loose bolts.



Adjustable leveling feet

( This part is already attached on the end cap of 4 legs. )

.....  
Level the furniture, use leveling feet if needed.