

Floor lamp

■ Specification

Voltage: 110-130V

Wattage: 100 Watt Max

Material: Meta + Wood

Lamp holder: E26

Wire Length: 96in/2440mm

Usage: Indoor use only

■ Package Include

1 x Lampshade

1 x Lamp Base

2 x Metal rings



1 x Finial&Harp

1 x A19 Led Bulb

1 x User Manual


■ Easy Installation

1. First, connect the shade sides with Velcro. Align the ring frame to the shade edge and snap it into the edge clips. Repeat for the second frame. Ensure frames are secure and shades are tight.
2. Fasten Socket Assembly into Tube(A) be careful not to twist power cord.
3. Fasten Tube(A) into Tube(B) be careful not to twist power cord.
4. Fasten Tube(B) into Tube(C) be careful not to twist power cord.
4. Fasten Tube(C) onto Base be careful not to twist power cord.
6. Attach two legs of the lamp harp to the saddle.
7. Install the bulb.
8. Fix the lampshade on the lamp harp.
9. Screw the finial to secure the lampshade. (When the lampshade is tilted, refer to the lampshade adjustment instructions below.)



■ Adjust the angle of

If the shade tilts, press the higher side down to level it. Some force may be needed — this is normal.



■ Attention

1. If replacing the included 2700K vintage LED bulb, use a bulb under 60W only.
2. The bulb may get brighter near end of life or if partially short-circuited. If this happens, turn off the lamp, replace the bulb, and resume normal use.
3. Always turn off and unplug the lamp before changing the bulb.
4. Do not operate the lamp in extreme heat or throw it into fire.