



Ax2	Bx1	Cx4	Dx2	Ex2	Fx2	Gx4
Hx3	Ix24 6x16mm	Jx21 8x30mm	Kx12 6x35mm	Lx21	Mx21	Nx60
Ox60	Px12	Qx4	Rx1			

**SPARE Parts**

Ix1 6x16mm	Jx1 8x30mm	Kx1 6x35mm	Lx1	Mx1
Nx1	Ox1	Px1		

### Step1

J	8x30mm	21
L		21
M		21
R		1

### Step2

I	6x16mm	12
N		12
O		12
R		1

### Step3

I	6x16mm	6
N		6
O		6
R		1

### Step4

I	6x16mm	6
N		6
O		6
R		1

### Step5

K	6x35mm	12
N		12
O		12
P		12
R		1

### Step6