



ASSEMBLY INSTRUCTION

DRESSER

BEFORE YOU START ASSEMBLING,
PLEASE MAKE SURE ALL PARTS & HARDWARE ARE INCLUDE IN BOX :

NO	PARTS	QTY
I	DRESSER	1 PC

NO	HARDWARE	QTY
A	SCREW \varnothing 8 x 2"	1 PC
B	SCREW \varnothing 8 x 5/8"	1 PC
C	METAL ANCHOR	2 PCS
D	RESTRAIN STRAP	1 PC
E	FISCHER	1 PC



WARNING

Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tipover:

- Install tipover restraint provided.
- Place heaviest items in the lower drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time. (OR)
- Do not defeat or remove the drawer interlock system.

Use of tipover restraints may only reduce, but not eliminate, the risk of tipover.

This is a permanent label. Do not remove.