



Recline & Reset:



Hand Controller Functions:



Power Button:	Press once to turn on (indicator light on, enters random massage mode). Press again to turn off.
Intensity Button:	3 levels adjustable, press to cycle. Default: Medium (M).
Mode Button:	3 vibration modes adjustable. Press to cycle. Default: M1.
Zone On/Off Button:	Select vibration areas. Available only in M2 mode.
Heating Button:	Press to activate heating pad (indicator light on). Press again to turn off. Auto shut-off at 65°C.
Temperature Button:	Adjustable after heating starts. Press to cycle. Default: M1. $\pm 10^{\circ}\text{C}$ variation due to environment.
Timer Button:	Set auto shut-off at 15/30/60 minutes (cycle).

 Do not insert head, hands, or feet under sofa frame while operating.