



21001391 / MLM-210638



ASSEMBLY INSTRUCTIONS


PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.




FS


1




2





3



4




Bench





Do not fully tighten bolts until assembly is complete.

3seat corner sofa



3seat sofa



Dining table

