
Assembly Instructions



⚠ WARNINGS

English
Two people are required to assemble this product
Do not tighten screws until fully assembled.
Do not place heavy objects on the egg chair.
Warning: Weight limit for the egg chair is 250lbs (113.39Kg).
When not in use, secure the product in a cool and covered location.
Check all screws or bolts are tightened and inspect regularly.

⚠ WARNUNGEN

Deutsch
Zur Montage dieses Produkts werden zwei Personen benötigt.
Schrauben erst festziehen, nachdem die Montage vollständig abgeschlossen ist.
Keine schweren Gegenstände auf den Eiersessel stellen.
Warnung: Gewichtsgrenze für den Eiersessel beträgt 113,39 kg.
Bei Nichtgebrauch das Produkt an einem kühlen und überdachten Ort sichern.
Überprüfen Sie, ob alle Schrauben oder Muttern festgezogen sind, und inspizieren Sie sie regelmäßig.

⚠ AVERTISSEMENTS

Français
Le montage de ce produit nécessite deux personnes.
Ne serrez pas les vis avant que le montage ne soit complètement terminé.
Ne placez pas d'objets lourds sur le siège œuf.
Avertissement : La limite de poids pour le siège œuf est de 113,39 kg.
Lorsqu'il n'est pas utilisé, placez le produit dans un endroit frais et couvert.
Vérifiez que toutes les vis ou boulons sont serrés et inspectez-les régulièrement.

⚠ AVVERTENZE

Italiano
Per montare questo prodotto sono necessarie due persone.
Non serrare le viti fino a quando il montaggio non è completo.
Non posizionare oggetti pesanti sulla sedia uovo.
Avvertimento: Il limite di peso per la sedia uovo è di 113,39 kg.
Quando non in uso, fissare il prodotto in un luogo fresco e coperto.
Controllare che tutte le viti o i dadi siano serrati e ispezionare regolarmente.

⚠ ADVERTENCIAS

Español
Se necesitan dos personas para ensamblar este producto.
No apriete los tornillos hasta que el ensamblaje esté completo.
No coloque objetos pesados sobre la silla huevo.
Advertencia: El límite de peso para la silla huevo es de 113,39 kg.
Cuando no esté en uso, asegure el producto en un lugar fresco y cubierto.
Compruebe que todos los tornillos o tuercas estén apretados e inspeccione regularmente.



Cleaning & Maintenance

For best results, clean the frame and fabric with a damp cloth and dry thoroughly.
This will help prevent mildew by removing dirt particles that may accumulate.
Do not clean with abrasive materials, bleach, or solvents.
Store the egg chair in a dry, sheltered place when not in use.
Keep the egg chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

PART NAME


A	B	G	D	E
				
x2	x1	x1	x1	x2

F	C	H	I	J
				
x2	x4	x2	x4	x2


K	L	M	N	O
				
M10*70L x4	x4	x2	x1	x1


P	Q	R	W	O1
				
x1	M6*15 x10	M6 x8	M6 x2	x1

PART NAME


A3	A5	Q3	Y	
				
x1	M6 x1	x1	x1	


Step:1







Step:2







Step:3









Step:4





Step:5






Step:6






PRODUCT ILLUSTRATION

• 0-5 levels from bottom to top




• Further raise the angle again from level 5, and the leg rest will return from level 5 to 0



CORRECT SEATING STEPS


Step 1

• Return the leg rest to the 0th level
• Easy to get into the hanging basket
• Do not press the leg rest forcefully




Step 2

• Hold the hanging basket and sit inside




Step 3

• After sitting in the basket, use your toes to hook and lift the leg rest, adjusting it from Level 0 to 5.



Step 4


• Adjust to a comfortable sitting/lying position



CORRECT WAY TO GET OFF


STEP 1

• When you lift the angle further from Level 5, the leg rest will return from Level 5 to 0



STEP 2


• Once the leg rest is back to Level 0, you can sit in the hanging chair



STEP 3

• With the leg rest at Level 0, you can stand up and get off






INCORRECT USAGE

WARNING 1

• Do NOT step on the leg rest, or it may break



WARNING 2

• Do NOT sit on the leg rest, or it may break

