



LAUNDRY HAMPER STORAGE CART: USE + CARE INSTRUCTIONS

- Keep the cart in a cool, dry, and ventilated place.
- Do not soak the cart in water or expose the hamper to the sun.
- Keep away from fire.
- Wipe clean only.
- Keep the cart on a level surface.
- Handle with care. The cart may have sharp or splintered edges. Always protect your hands. Do not use if the cart is damaged.
- Be careful not to pinch fingers.
- Do not wash the ironing board.
- Do not place the heating plate of an iron in direct contact with the ironing board to avoid burning the board.

©2022 The AMES Companies, Inc. | Orlando, FL 32827 | 1-800-874-0008 (USA, Canada) | www.closetmaid.com



LAUNDRY HAMPER STORAGE CART: USE + CARE INSTRUCTIONS

- Keep the cart in a cool, dry, and ventilated place.
- Do not soak the cart in water or expose the hamper to the sun.
- Keep away from fire.
- Wipe clean only.
- Keep the cart on a level surface.
- Handle with care. The cart may have sharp or splintered edges. Always protect your hands. Do not use if the cart is damaged.
- Be careful not to pinch fingers.
- Do not wash the ironing board.
- Do not place the heating plate of an iron in direct contact with the ironing board to avoid burning the board.

©2022 The AMES Companies, Inc. | Orlando, FL 32827 | 1-800-874-0008 (USA, Canada) | www.closetmaid.com



LAUNDRY HAMPER STORAGE CART: USE + CARE INSTRUCTIONS

- Keep the cart in a cool, dry, and ventilated place.
- Do not soak the cart in water or expose the hamper to the sun.
- Keep away from fire.
- Wipe clean only.
- Keep the cart on a level surface.
- Handle with care. The cart may have sharp or splintered edges. Always protect your hands. Do not use if the cart is damaged.
- Be careful not to pinch fingers.
- Do not wash the ironing board.
- Do not place the heating plate of an iron in direct contact with the ironing board to avoid burning the board.

©2022 The AMES Companies, Inc. | Orlando, FL 32827 | 1-800-874-0008 (USA, Canada) | www.closetmaid.com



LAUNDRY HAMPER STORAGE CART: USE + CARE INSTRUCTIONS

- Keep the cart in a cool, dry, and ventilated place.
- Do not soak the cart in water or expose the hamper to the sun.
- Keep away from fire.
- Wipe clean only.
- Keep the cart on a level surface.
- Handle with care. The cart may have sharp or splintered edges. Always protect your hands. Do not use if the cart is damaged.
- Be careful not to pinch fingers.
- Do not wash the ironing board.
- Do not place the heating plate of an iron in direct contact with the ironing board to avoid burning the board.

©2022 The AMES Companies, Inc. | Orlando, FL 32827 | 1-800-874-0008 (USA, Canada) | www.closetmaid.com