




# Assembly Instructions

Caution :You must read this before you proceed




## Club Chair



### Parts List

Label	Picture	Description	QTY
A		Chair Base	1
B		Leg	4

### Hardware

Label	Picture	Description	QTY
①		Allen Key	1
②		Bolt M8X40	13
③		Spring Washer Ring	13


④



Flat Washer Ring

13

## Assembly Preparation



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


## Assembly Steps



**FRONT FACING**


This Club Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Club Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

### Step 1




Position the chair on its back, as shown.  
Unzip to open pouch and remove the 4 wooden legs, close the pouch.

### Step 2




Install the Legs (B) to Chair Base (A) by using the Bolt (2), Spring Washer Ring (3), Flat Washer Ring (4) as shown. Use the Allen Key (1) to fasten all bolts.  
Repeat the same process to install the remaining three Legs.  
Caution: Do not fully tighten.

### Step 3























Place the Chair on a LEVEL SURFACE to see if it wobbles.  
If it wobbles, press firmly down on Seat and Armrests at the same time.  
This will help to ensure all Bolts and gaps reach full alignment status.  
If no wobbles found, proceed to tighten all the bolts. DO NOT fully tighten a BOLT in one go and then move on to the next. Rather, In a sequential manner, gradually tighten each Bolt until all bolts are evenly secured.  
This methodology will ensure maximum evenness once all Bolts are fully tightened.  
Now tighten all the bolts until the chair is not wobbling on the LEVEL SURFACE.

Step 4



Your Club Chair is ready for use.  
Your Club Chair can only be used on a flat, level surface.

## Care & Maintenance

-   ● Do not put hot items directly on furniture surface
  -   ● Do not clean furniture with harsh cleansers or polish.
  -   ● Do not place furniture under direct sunlight.
  -   ● Do not place furniture near heating or cooling vents.
  -   ● Do not write on furniture without a padded barrier to protect the surface.
  -   ● Do not place furniture outside . For indoor use only .
  -   ● Not for commercial use. For residential use only .
  -   ● Stains may be removed with mild soap solution and damp cloth.
  -   ● Children should not climb or jump on the furniture.
- 
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

### Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

### Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disneyland Resort has a Proposition 65 warning:

