

1: Add Pure gasoline because it's a four-stroke machine



2: Fill engine oil: 10W-30 HIGH DETERGENT MOTOR OIL



3: Starting engine, please refer to the video.

- Move the fuel valve lever to the ON position.



- To start a cold engine, move the choke to the CLOSE position; To restart a warm engine, leave the choke lever in the OPEN position.



- Turn the engine switch to the ON position



- Pull the recoil starter, Pull the starter grip lightly until you feel resistance, then pull briskly, return the starter grip gently.



- Move the throttle lever away from the SLOW position, about 1/3 of the way toward the FAST position.



- Operate the starter.

- If the choke lever has been moved to the CLOSE position to start the engine, gradually move it to the open position as the engine warms up.