


Installation Instructions







***Tips for height adjustment:**

To Lower the Seat: step on the step pedal all the way down to lower the seat.

To Raise the Seat: consecutively step on the step pedal halfway to slowly raise the seat to a higher position.

Please do not hesitate to if there are any problems with the items.

Please also leave us the order number and the pictures or videos of the item, and we will reply to you within 48 hours.











Assemble with the assistance of another person.

Carefully protect the product during installation.




Parts Included





A*1  Seat	B*1  Backrest	C*1  Seat Cushion	D*1  Footrest	E*2  Footrest Support
--	---	--	---	---

F *1  F1 *1 	G1*1 	G2*1 	H*4 	I*4 	J*1 	K*1 	L*1  Base	M*1  Pump	N*1  Step Pedal
Wrench			Screws						



1 Install the base and pump



1-1. Secure the pump cover with J.





1-2. Secure the pump and base with H and I.



F*1 	G1*1 	H*4 	I*4 	J*1 	L*1 	M*1 
Wrench		Screws			Base	Pump

2 Install the step pedal

2-1. Insert N into the pump and tighten the screw.



Pay attention to the orientation of N.



F*1 	N 
Wrench	Step Pedal





3 Install the seat to the pump

Two person are recommended to complete this step.

3-1. Place the seat onto the pump (please note the pinon the pump toward the gap of the pump joint).

3-2. Insert the screw into the screw hole of the seat.

3-3. Tighten the screw to secure the seat and pump.








4 Install the Footrest

4-1. Remove the screws pre-installed on both sides of the footrest.

4-2. Align the screw holes of the footrest and the seat, insert the 2 screws, and then tighten the nuts with the tools.

4-3. Tighten the 2 foot supports to the bottom of the footrest.



5 Install the Footrest



5-1. Remove the screws and nuts pre-installed on both sides of the footrest connector as shown in the picture.

5-2. Align the screw holes of the connector and the footrest, insert the screws removed from the previous step, and then tighten the nuts with the tools.

F1*1



G1*1




6 Install the Seat Cushion to the Seat

6-1. Remove the screws and the black baffles pre-installed on the seat.




6-2. Put the seat cushion on the seat, put on the baffles and insert the screws, and tighten the screws with the tool.

C*1



Seat Cushion

F1*1








7 Install the Backrest to the Seat

7-1. Remove the 3 nuts pre-installed on the back rest.


7-2. Align the screw holes of the back rest and the seat, insert the back rest to the seat.

7-3. Tighten the nuts remove from the previous step with the tool.

7-4. Sit on the chair for a while to make the seat more firmly connected with the pump and avoid the chair being wobbly



Installation Completed.



Please feel free to contact us if there are any problems with installation or items. We will reply to you within 24 hours.