












# 17" CLOCHE PENDANT

## Assembly Instructions

### PARTS:

ITEM	DIAGRAM	DESCRIPTION	QTY.
(A)		OUTLET BOX	0
(B)		THREADED TUBE	1
(C)		CROSS BAR	1
(D)		MOUNTING SCREWS	2
(E)		CANOPY	1
(F)		CEILING LOOP	1
(G)		CHAIN	1
(H)		S-hook	1
(I)		WIRE CONNECTORS	2
(J)		Nut	2
(K)		Lock Washer	2

### IMPORTANT SAFETY ASSEMBLY INSTRUCTIONS:

\* These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

\*TURN OFF ELECTRICITY AT MAIN CIRCUIT BREAKER PANEL BEFORE BEGINNING INSTALLATION.\*

\*THIS DIRECT WIRE FIXTURE MUST BE INSTALLED BY A CERTIFIED AND LICENCED ELECTRICIAN. Customer should not attempt to install.\*

### WARNINGS:

\*DUE TO WEIGHT OF THIS ITEM, THE MINIMUM RATING ON YOUR CEILING OUTLET BOX MUST BE 100 LBS. FOR FIXTURES. IT'S IMPERATIVE THAT YOU FOLLOW THE MANUFACTURER'S INSTRUCTIONS FOR CEILING OUTLET BOX INSTALLATION.\*

\* IF ANY SPECIAL CONTROL DEVICES ARE USED WITH FIXTURE, FOLLOW THE INSTRUCTION CAREFULLY TO ASSURE FULL COMPLIANCE WITH N.E.C. REQUIREMENT. IF THERE ARE ANY QUESTIONS, CONTACT A LICENCED ELECTRICAL CONTRACTOR.\*

### ASSEMBLY:

1. Measure desired drop for fixture to hang from ceiling. Remove any unnecessary links from chain (G) using a chain-break tool (not included).

2. Attach cross bar (C) with threaded tube (B) to ceiling outlet box (A) using mounting screw (D). Adjust the length of threaded tube (B) to its desired position by using attached nut (J) & Lock Washer (K).

**NOTE: DUE TO THE WEIGHT OF THIS ITEM, THE MINIMUM RATING ON YOUR CEILING OUTLET BOX MUST BE 100 LBS. FOR FIXTURES.**

3. Take out the S-hook (H) and detach the pendant from the ceiling loop (F) for easy installation.

4. Pull wire through threaded tube (B) from ceiling outlet box (A) to make proper electrical connections described in step 5-7.

5. Attach ground wire tagged with YELLOW label from fixture to cross bar with screw (included with hardware).

6. Attach HOT wire tagged with RED label from fixture to hot wire from outlet box and tight with wire connector (I).

7. Attach neutral wire tagged with Green label from fixture to neutral wire from outlet box and tight with wire connector (I).

8. Slide canopy (E) up and hold flush against ceiling and screw the ceiling loop (F) onto the threaded tube (B). Use the S-Hook (H) to join the chain (G) with ceiling Loop (F).

### CARE INSTRUCTION:

\*\*To clean, use a soft cloth only. DO NOT use any chemical or abrasive cleaners.\*\*

### Wiring Information

Hot Wire: Red Label

Neutral Wire : Green Label

Ground Wire : Yellow Label

### Mounting Assembly Instruction

