









INSTRUCTION MANUAL REC



220~240V
50Hz



Loosen the screws and adjust the
required height



230V~50Hz