


















Suggestion

- It is recommended to install it near a power source, as later steps will require the power to be turned on.
- This product requires installation by at least two people.




















ASSEMBLY INSTRUCTION























ASSEMBLY INSTRUCTION

①  1PC	②  1PC	③  2PCS	④  2PCS
⑤  2PCS	⑥  1PC	⑦  1PC	⑧  2PCS
⑨  1PC	⑩  1PC	⑪  2PCS	⑫  2PCS
⑬  1PC	⑭  1PC	⑮  1PC	⑯  1PC
⑰  1PC	⑱  1PC	⑲  1PC	⑳  1PC





ASSEMBLY INSTRUCTION

②1 1PC 	②2 1PC 	②3 1PC 	②4 1PC 
②5 1PC 	②6 1PC 	②7 1PC 	②8 1PC 
②9 1PC 	③0 1PC 	③1 1PC 	③2 1PC 
③3 1PC 	③4 1PC 	③5 1PC 	③6 1PC 
③7 1PC 	③8 1PC 	③9 1PC 	④0 1PC 





ASSEMBLY INSTRUCTION

④1 1PC 	④2 1PC 	④3 2PCS 	④4 1PC 
④5 1PC 	④6 2PCS 	④7 2PCS 	④8 3PCS 
④9 2PCS 	⑤0 1PC 	⑤1 1PC 	⑤2 1PC 
⑤3 1PC 	⑤4 2PCS 	⑤5 1PC 	⑤6 1PC 
⑤7 1PC 	⑤8 1PC 	⑤9 1PC 	⑥0 1PC 







ASSEMBLY INSTRUCTION

⑥1	1PC	⑥2	2PCS	⑥3	1PC	⑥4	2PCS
							
⑥5	1PC	⑥6	1PC				
							

"A" Hardware installation example

I	II
 This part cannot be separated , please install in strict accordance with the assembly requirements	
III	IV
	

ASSEMBLY INSTRUCTION
















A 12PCS  M6*30	B 10PCS  M6*10	C 1PC  M4	D 4PCS  M6*10
E 6PCS  14"	F 2PCS  M8	G 1PC 	H 4PCS 
I 1PC 	J  4PCS  8PCS	K 125PCS  M6*40	L 125PCS  Ø15*9.5
M 88PCS  Ø3.5*14	N 12PCS  Ø3.5*40	O 12PCS  Ø5*15	P 6PCS 
Q 1set      	R 16PCS 	S 2PCS  Ø50	T 1PC 
U 11PCS  Ø8*40	V 2PCS 	W 16PCS  M6*16	X 2PCS  M8*16
Y 8PCS  M8*90	Z 16sets     M8	125PCS 	 M4  M5  

Step 1

K 113PCS






M6*40





Step 2

K 12PCS
M6*40




Step 3

L 3PC
Ø15*9.5



Step 4

L 2PCS
Ø15*9.5




ASSEMBLY INSTRUCTION

Step 5

L 1PC


Ø15*9.5



Step 6

L 5PCS


Ø15*9.5



Step 7

L 2PCS


Ø15*9.5



Step 8

L 10PCS


Ø15*9.5



ASSEMBLY INSTRUCTION

Step 9


L 6PCS
Ø15*9.5



Step 10


G 1PC

M 2PCS
Ø3.5*14




Step 11

L 11PCS
Ø15*9.5




Step 12



M 4PCS
Ø3.5*14





Make sure the accessory nuts face outward during installation.






Step 13





Step 14




Step 15



Step 16




Step 17




Step 18

M 8PCS
Ø3.5*14




Step 19

L 3PCS
Ø15*9.5



Step 20

L 3PCS
Ø15*9.5




ASSEMBLY INSTRUCTION

Step 21

L 6PCS


 Ø15*9.5



Step 22

L 4PCS


 Ø15*9.5



Step 23

L 4PCS


 Ø15*9.5



Step 24


L 7PCS

 Ø15*9.5




Step 25

E 6PCS



Ex6




Step 26

M 12PCS



Ø3.5*14

E1 6PCS




ASSEMBLY INSTRUCTION

Step 27

L 5PCS


 Ø15*9.5



Step 28

L 5PCS


 Ø15*9.5



Step 29

L 12PCS


 Ø15*9.5



Step 30

L 18PCS


 Ø15*9.5




Step 31

M 4PCS


 Ø3.5*14



Make sure the accessory
nuts face outward during
installation.




Step 32




A	4PCS
	
	M6*30
Q5	1PC
	
Q6	2PCS
	
	Ø3.0*15

Step 33




R	10PCS
	





Step 34



Step 35





Step 36




E2	2PCS	L	4PCS
			
14"		Ø15*9.5	
M	4PCS	N	4PCS
			
Ø3.5*14		Ø3.5*40	

Step 37




Step 38

0 8PCS
Ø5*15



Step 39


M 8PCS
Ø3.5*14
P 4PCS



Step 40

M 16PCS


Ø3.5*14



Step 41


L 6PCS

Ø15*9.5




Step 42


Attention, please! Lift accessory 1 and accessory 2 up by hand to the same level to facilitate the installation of accessory 5 in step 43.



Step 43



Note that the "gourd-shaped hole" here on the front crossbeam is close to the left cabinet




B	4PCS
	
	M6*10
C	1PC
	
	M4

First install the inner screw, then install the outer screw.


Step 44

Attention, please! Install accessory 5, which is the crossbeam, and press the legs on both sides to the lowest position.



If it is not pushed all the way to the bottom, it may cause the product to have uneven legs, which can result in an uneven tabletop.




Step 45



B 2PCS
M6*10



Step 48



C	1PC
	M4
F	2PCS
	M8
I	1PC


Note: If the transmission rod doesn't fit smoothly into the hole of rod coupler, fine-tune it with the wrench.

Step 49


Step1: Connect the controller of the lifting frame, namely accessory 6, to the plugs of the other two accessories 10 and 13, and then turn on the power.

Step2: Press the downward button on the controller for 5 seconds- the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.

Step3: Press and hold the "Rise" button, raise the lifting frame to a certain height, then turn off the power and proceed to the next installation step.




Step 50



Step 51


B 4PCS

M6*10




Step 52

A 4PCS
M6*30




Step 53

D 4PCS
M6*10




Step 54

U 4PCS
Ø8*40




Step 55

U 8PCS
Ø8*40
Y 8PCS
Ø8*90




Step 56



Z1	16PCS
Z2	16PCS
Z3	16PCS
M8	
Z4	16PCS

Step 57





W	16PCS
M6*16	

Attention, please! At this step, screw W cannot be locked yet. All 16 screws need to be locked before tightening screw W uniformly.

Wx16


Step 58

S	2PCS	M	2PCS
			
Ø50		Ø3.5*14	



Step 59

H	4PCS
	
M	4PCS
	
Ø3.5*14	
T	1PC
	




To prevent the power adapter from being damaged and from loosening, please use a pull strap to secure the cable.

Step 60


X2PCS



M8*16



Step 61



OK

Instruction Manual for JCB35M51C Controller (Version 1.0-English)


System Function Description:

1. Lifting and Lowering Function of the Height-Adjustable Desk:

Hold down the upward button, and the column will rise; hold down the downward button, and the column will lower. Release the button, and the movement will stop.

2. Memory Position Function:

Long press the "①/②" button for 3 seconds until the digital tube display flashes. After the number flashes 3 times and stops, the current height will be successfully stored in the corresponding memory position. Short press the "①/②" button and release it, and the tabletop will automatically move to the height of the memory position. During operation, pressing any button can stop the movement.



3. Reset Function:

(1) Function Description:

The system needs to be reset under specific circumstances.

These circumstances include:

- ① When used for the first time, the system will enter the reset state after being powered on.
- ② Active reset will put the system into the reset state.
- ③ A system abnormality will cause the system to enter the reset state.

(2) Operation Method:

Bottom Reset: Hold down the downward button until it reaches the bottom. Then release the button, and press the downward button again for 5 seconds—the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.

