




**USER'S MANUAL / HANDBUCH / MANUEL DE L'UTILISATEUR /
MANUAL DEL USUARIO / MANUALE UTENTE /
INSTRUKCJA OBSŁUGI**

**Wooden Kitchen Storage Trolley / Küchenwagen /
Chariot de Cuisine / Carro de Cocina / Carrello da Cucina /
Wyspa kuchenna**




(M6x30mm) A x10	(M5x40mm) B x6	(M4x25mm) C x8	(M5x16mm) D x16	(M3x18mm) E x8	(M4x12mm) F x24	(M4x18mm) G x6		(M6x30mm) I x14	(M4x30mm) J x6
				(M6x12mm) O x10	(M6x11mm) P x10	(M6x35mm) Q x1			
			(M3.5x12mm) X x12						

1




x2


2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17



18



19



20

