





DINING CHAIR ASSEMBLY INSTRUCTIONS




Assembly accessories




① × 2




② × 2



③ × 1




④ × 13




⑤ × 13

Notes: The accessories include 1 spare screw
and 1 spare gasket.



Install the front legs



Install the back legs

