



# TV Stand Assembly Instructions




# PACKAGE CONTENT




# PACKAGE CONTENT




34x




34x



37x




14x




M4x12mm

4 x




8x



2x




4x




8x




4x




4x




2x




1x



1x




1x




M4x35 mm

4x


# 1



# 2




# 3




---


# 4




5




6




7




8




9




10



# 11





# 12






# 15




---


# 16



17



18



19

