

ASSEMBLY INSTRUCTIONS

ROUND TABLE

ASSEMBLY	2-Person	Assembly Time	30 Minutes	Tools Required
Requirements	Assembly	(Approximate)	(Not Provided)	Socket wrench

Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damage parts or hardware. Replacement parts are normally shipped within 2 or 3 days.

PRODUCTS PURCHASED THROUGH OUR AUTHORIZED VENDORS ONLY ARE ELIGIBLE FOR REPLACEMENT PARTS

We appreciate your business!

THIS PRODUCT IS FOR INDOOR AND HOUSEHOLD USE ONLY – NOT FOR COMMERCIAL USE.

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly. Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.

SAFETY PRECAUTION

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY

1. Allow ample room for assembly and assemble the product near where it will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- Do not drag and/or pull the furniture.

Parts and Hardware List




Table Top

A. 1PC



Table Base

B. 1PC




Center Tube

C. 1PC



Cross Bar

D. 1PC



Big Screw

E. 1PC



Hex Screw

F. 4PCS




Spring Washer

G. 4PCS




Flat Washer

H. 1PC



Nut

I. 1PC



Wrench


L. 1PC



Big Allen Key

K. 1PC

STEP 1




Please ensure there are two black pads on Cross Bar (D). They are needed to tighten Cross Bar (D) on (C) firmly.

- Place Cross Bar (D) over and perpendicular to the cross bar on Center Tube (C) as shown.
- Use Big Screw (E) fitted with Flat Washer (H) to fasten Cross Bar (D) to Center Tube (C). Use Big Allen Key (K) to drive and tighten (E) completely.

Note: Please ensure that Big Screw (E) is tightened fully before move to step 2.

STEP 2



There is a round white Nylon inside of Nut (I). It serves to tighten screw firmly and prevent screw to become loose over time. Ensure Nut (I) is tighten completely to fasten the (B) fully to (C).

- Set Center Tube (C) assembly from STEP 1 upside down.
- With assistance place Table Base (B) onto (C) by fitting the bolt hole in the center of (B) to the bolt on top of (C).
- Use Nut (I) to fasten (B) to (C) via bolt on top of (C). Use Wrench (L) to drive and tighten (I) completely.

STEP 3

- a) With assistance, lay the table top (A) bottom-side up on a material that does not damage its surface.
- b) Position assembly from STEP 2 to align screw holes on Cross Bar to the screw holes on bottom-side of (A).
- c) Use Hex Screw (F) fitted with Spring Washer (G) to fasten (A) to Cross Bar on Center Tube. Use Allen Key (J) to drive (F). Tighten (F) completely only when all 4 screws are in place .



STEP 4

With assistance, turn the table right-side up.
The assembly of the table is complete.

