


QUESTIONS REGARDING THIS PRODUCT? Call our customer-service line toll-free.

Your box should contain:

- 1 - Rope hammock with chain assembly
- 1 - Fabric hammock pad
- 1 - Hammock pillow
- 1 - Hammock stand, unassembled:
 - 2 - Bolt hooks and nuts
 - 2 - Welded foot poles
 - 2 - 60-inch arm poles
 - 1 - 51-inch center pole
 - 2 - Round protective pole caps *



* For your convenience,
round protective pole
caps are already fitted
into their respective poles.



**Before beginning assembly,
make sure you have all parts.**

Tools you'll need:

13 mm wrench,
or adjustable wrench



FIGURE 1

FIGURE 1




FIGURE 2



FIGURE 3



FIGURE 4

STEP 1. Place one foot pole flat on the ground with the small, curved pipe facing upward, lining up the end of the curved pipe opposite the weld to one end of your center pole. (FIGURE 1). Depress the steel pin on the narrower pole, then slide the wider pole over the narrower pole (FIGURE 2) until the pin clears the lip of the wider pole and pops out the hole (FIGURE 3). Repeat this step with the opposite end of the center pole and the remaining foot pole to create the stand's base.

STEP 4. Using the spring pin, attach the uncapped end of one arm pole to the remaining curved pipe of one foot pole. (**FIGURE 4**). Repeat with other foot and arm poles.



FIGURE 5



FIGURE 6



FIGURE 7

STEP 3. Remove the attached nut from one bolt hook, inserting the hook into the hole near the capped top of one stand arm (**FIGURE 5**), the threaded end of the bolt coming out the corresponding hole at the back of the pole. Loosely attach the nut to the hook's threaded end, using your wrench to tighten (**FIGURE 6**); do not overtighten. Unroll the hammock and attach a link of chain at each end to the bolt hooks now fitted to each stand arm (**FIGURE 7**); adjust chain lengths to change your hammock height. Hammock ropes will stretch the first few times the hammock is used; once they've stretched completely, readjust the hammock-chain links to achieve your most comfortable hanging height.



FIGURE 8



FIGURE 9

STEP 4. Loosely center the unfolded hammock pad atop the hammock, with the pad's tie-on straps underneath. Using a simple knot, tie the straps at both ends of the pad to the wooden spreader bars at each end of the hammock (**FIGURE 8**), then tie the straps at the pad's middle to the rope braid running along the hammock's side (**FIGURE 9**). If you don't like the ends of the straps hanging down, you can tuck them underneath the pad itself.



FIGURE 10

STEP 5. Center the hammock pillow at one end of your hammock pad. Using a simple knot, attach the two sets of ties to the hammock spreader bars beneath the pad (**FIGURE 10**). Tuck the strap ends beneath the pad if you don't like them dangling.

WARRANTY | Products guaranteed free of defects in workmanship and materials for up to one year from date of purchase. If an item is found to be defective within that time, we will replace it at no charge. Normal wear and tear, including prolonged exposure to snow, rain and heavy humidity, is not covered, nor is mold, mildew or damage from improper storage, maintenance or installation. An original sales receipt must accompany any returned product, along with a Return Authorization Number from our customer service; call our toll-free.

Hammock care and safety tips, see reverse side >>>>>>>>>>

HAMMOCK SAFETY

- **INSPECTION:** To ensure overall hammock safety, a hammock should be inspected for damage or excessive wear-and-tear each time someone gets into it.
- **WEIGHT LIMIT:** Appropriately installed and cared for, this hammock has a weight limit of 350 pounds.
- **GETTING INTO YOUR HAMMOCK:** To get safely into a hammock, a person should place his or her weight in the center of the fabric, not on either edge. Don't rush it; getting into a hammock incorrectly can flip a person right back out again.
- **KIDS AND HAMMOCKS:** Young children should **never** be allowed to use this or any hammock without adult supervision. Infants should **never** be placed in a hammock, period. Children should also not be allowed to jump up and down in a hammock or use it like a playground swing. Not only is this extremely dangerous, but it puts excessive wear-and-tear on the hammock and its hanging hardware.
- **MAINTAIN THE CHAIN:** Keep the hanging chains from becoming twisted, and the hammock from staying flipped upside down while it's hung; both severely compromise chain strength.
- **REPLACEMENT HOOKS:** Do not replace offset "S" hooks with other hardware; the hooks that come with the stand are specially designed for it. For replacement hooks, contact our toll-free.



HAMMOCK MAINTENANCE AND CARE

There are a few simple things that can be done to ensure your hammock's longest possible life:

- **WEATHER WEAR:** Repeated exposure to rain, snow and sleet will eventually begin to shorten the hammock's useful life and affect its appearance. This hammock should be stored in a clean, dry place during prolonged stretches of bad weather, and taken down in winter in locales where weather is consistently severe.
- **DEBRIS DAMAGE:** Especially in fall, check the hammock periodically to rid it of leaves and twigs that easily become lodged in the rope, or build up on the hammock pad. If this material begins to rot while in contact with rope or fabric, it could become potentially harmful to the hammock itself.
- **WILDLIFE WOES:** Squirrels, mice, birds and bugs sometimes use hammock-rope fibers to build nests with, and even to live in, so this hammock should always be inspected for safety before getting into it, especially after long periods when the hammock has not been in use.
- **PUPPY PROBLEMS:** Man's best friend is not always a hammock's best friend! Dogs, especially puppies, often regard hammocks as great chew toys, so dog owners should hang, and store, their hammocks somewhere Rover can't easily reach.
- **HARSH CHEMICALS:** Avoid storing this hammock and its accessories near strong chemicals, including pesticides, which may damage the integrity of the different parts.
- **CLEANING THE HAMMOCK:** To clean this hammock, stretch it out on a clean, dry, non-abrasive surface, then wet it with a hose and gently scrub the ropes with a soft brush and a mild soap/warm-water solution. When finished, rinse with the hose. Do **not** use bleach or any cleaning product containing it or other strong chemicals. Once this hammock has been washed, rinse it thoroughly and allow it to dry completely before it's hung back up or put away for storage.
- **CLEANING PAD AND PILLOW:** Spraying the fabric with a garden hose should take care of most cleaning issues. If more extensive cleaning is necessary, a soft brush and a mild soap/water solution should again do the trick. Rinse with the hose when finished, allowing fabric to air-dry before reusing.
- **CLEANING THE HAMMOCK STAND:** Periodically inspect the stand surface for any clinging debris, which should be wiped off to prevent long-term damage to the powder-coat surface. During periods of wet weather, do not leave the stand sitting in pools of standing rainwater.