











LIGHTWEIGHT ALUMINUM TELESCOPIC EASEL

INSTRUCTIONS • INSTRUCTIES • ISTRUZIONI
ANLEITUNG • INSTRUCCIONES • INSTRUÇÕES



- Do not use tools to loosen or tighten telescoping legs.
- No use herramientas para aflojar o apretar las patas telescópicas.
- Ne pas utiliser d'outils pour serrer ou desserrer les pieds télescopiques.



38010069