
ASSEMBLY INSTRUCTIONS meridia




314 - DRESSER / MIRROR



Do Not Use **Power Tools**



+ Suggested Adults




NOTE: For quetsions and about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

+ Parts Included

DRESSER (1)(1 pc)



MIRROR (1 pc)



MIRROR SUPPORT (3) (2 pcs)



1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part 1 DRESSER
- Part 2 MIRROR
- Part 3 MIRROR SUPPORT

Do not assemble if any of the following Hardwere parts are missing:


- Part D Allen Key Part A - Flat Washer
- Part B Spring Washer Part E Tipping Restraint
- Part C Bolt

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Hardware Included

A: Flat Washer(5/16"xØ19) (8 pcs)







C: Bolt (5/16" x 1-1/2") (8 pcs)

D: Allen Key (#4 x 3-1/8") (1 pc)







E: Tipping Restraint (1 set)



ASSEMBLY INSTRUCTIONS meridian.

314 - DRESSER / MIRROR





NOTE: For questions about parts or assembly please email support@meridianfurnitureusa.com or call us at 718-758-4455.