


ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # - Base
- Part # - Table Top
- Part # - Connection Panel

2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step

Assembly Step


***Warning:** Do not over tighten screws, or it could damage the Table Top.

+ Parts Included

①




②



③

+ Hardware Included

A



B



C

D




E

F


ASSEMBLY INSTRUCTIONS

1




Note: Do not over tighten screws

2



Note: Do not over tighten screws

3



ASSEMBLY INSTRUCTIONS

Cleaning Your Teak

- Teak can be generally cleaned with a hose. To remove any stains, gently sand away stained areas with fine-grit sandpaper. To maintain the teaks original color, occasionally sand the wood surface lightly and apply a teak protectant and cleaner.
- When choosing to keep your teak outdoors year round, we strongly recommend using an outdoor furniture cover to protect furniture from the elements and minimize aging.
- When storing your teak indoors, we recommend doing so in a watertight garage or storage shed (Caution: moving teak directly from an outdoor space into heated storage may cause the wood to split. This can happen when teak is exposed to drastic changes in temperature and humidity).

Cushion Care & Maintenance

- For surfaced teak oil stains, gently wash with a mild fabric cleaner and a soft-bristle brush. To avoid oil surfacing on cushions, flip cushions up when not in use until oil surfacing subsides (Set-in stains may require professional cleaning).
- For everyday stains, Use a mild cleaner with warm water and a soft-bristle brush. Rinse thoroughly and tip the cushions on zipper-side down, unzipped to ensure all water drains.