

Assembly Instructions





The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

Tools Required For Assembly:

Allen Wrench  (Included)

Wrench  (Included)

Phillips Screwdriver  (Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST,CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.
PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches . Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE.THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.





Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.


Parts List



#1 x 1pc
Headboard



#2 x 2pcs
Headboard leg (L&R)



#3 x 1pc
Headboard cross bar


#4 x 2pcs
Side rails



#5 x 1pc
Storage footboard



#6 x 2pcs
Footboard bunfoot



#7 x 1set
Slat 13pcs



#8 x 2pcs
Drawer support leg
150 x 30 x 30mm


Hardware List



#A x 8pcs
Bolt 5/16"-18 x 1-3/8"



#B x 16pcs
Lock Washer Ø5/16"



#C x 16pcs
Flat Washer Ø5/16"



#D x 2pcs
Allen key


#E x 2pcs
Bolt 1/4"-20 x 1-3/8"


#F x 2pcs
Lock washer Ø1/4"


#G x 2pcs
Flat washer Ø1/4"x19mm



#H x 26pcs
Screw Ø4 x 1-3/16"




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#9 x 8pcs
Slat support leg
385 x 30 x 30mm



#10 x 2pcs
Siderail top crown




#N x 10pcs
Lock washer Ø1/4"




#O x 10pcs
Flat washer Ø1/4" x13mm


Hardware List




#I x 8pcs
Thread rod 5/16" x 3-1/8"




#J x 8pcs
Half moon washer




#K x 8pcs
Hex nut (5/16")



#L x 1pc
Wrench




#M x 10pcs
Bolt 1/4" x 1-3/8"






Prepare 8 bolts assembly by inserting lock washer (#B), then flat washer (#C) onto bolts (#A). Align headboard (#1) and headboard cross bar (#3) to the holes of the headboard legs (#2R/L). Secure by using bolts (#A).

#A x 8pcs
#B x 8pcs
#C x 8pcs






Attach footboard bun foot (#6) to the bottom holes of the footboard (#5).






Attach support legs (#8) to the bottom holes of the footboard (#5). Adjust the leveler of the support legs (#8) according to ground level.






Attach treaded bolts (#I) to the foot board (#5) and headboard (#1). Align side rails (#4) to the threaded bolts of the foot board (#5) and headboard (#1). Secure by inserting half moon (#J), flat washer (#C), lock washer (#B) and hex nut (#K).

#B x 8pcs
#C x 8pcs
#I x 8pcs
#J x 8pcs
#K x 8pcs









Prepare 2 bolts assembly by inserting lock washer (#F), then flat washer (#G) onto bolts (#E). Align and secure foot board (#5) to the side rails (#4) by using bolts (#E).

#E x 2pcs
#F x 2pcs
#G x 2pcs






Attach support legs (#9) to the holes of the slats (#7). Adjust leveler of the support legs (#9) according to ground level.





Align slats to the side rails (#4), then secure by using screws (#H).

#H x 26pcs





Prepare 10 bolts assembly by inserting lock washer (#N), then flat washer (#O) onto bolts (#M).
Align side rail top (#10) to the holes of the side rails (#4), then secure by using bolts (#M).

#M x 10pcs
#N x 10pcs
#O x 10pcs

