




















# Assembly Instruction Montageanleitungen

<b>Ax5</b> 	<b>Ix2</b> 	<b>1</b> 	
<b>Bx1</b>	<b>Jx14</b>  M6*20mm		
<b>Cx5</b>	<b>Kx4</b>  M6*25mm		
<b>Dx1</b> 	<b>Lx2</b>  M8*20mm	<b>3</b>   Insert #E into the socket of #F (Insérez #E dans la prise de #F) (Fügen Sie #E in die Steckdose von #F ein) (Inserire #E nel socket di #F) (Insertar #E en el zócalo #F)	This side faces front of the chair (Ce côté fait face à l'avant de la chaise) (Diese Seite zeigt zur Vorderseite des Stuhls) (Questo lato è rivolto verso la parte anteriore della sedia) (Este lado está frente al frente de la silla) 
<b>Ex1</b> 	<b>Mx4</b>  M6*40mm		
<b>Fx1</b> 	<b>Nx1</b> 		
<b>Gx1</b> 	<b>Ox4</b> 		
<b>Hx1</b> 	<b>Qx4</b> 		
		<b>6</b> 	

## Massage function:

1. Connect the chair's USB plug to power source such as computer, power bank or power socket.
2. Turn on or off the massage function by pressing the "ON/OFF" button.
3. Press "MODE" to switch to different massage levels.

**100% Customer Satisfaction Guaranteed!**