


ASSEMBLY INSTRUCTION

MODEL NAME

MODEL NO.

COMPLETE ASSEMBLY



NO POWER TOOLS

PART LIST:

Part name	Part image	Quantity(pcs)
Wooden leg		4
Middle wooden leg		1
Nut		8
Screw		8
Washer		8
Allen key		1

Thank you for purchasing this quality product. Be sure to lay all components on a soft and clean surface before assembly in order to avoid component from being scratched.






CAUTIONS:

1. Check contents against list for quantity
2. Familiarize yourself with the components and hardware by reviewing the assembly instructions.
3. Do not over tighten the screws and bolts as it may damage the threads.
4. Keep all the hardware parts out of the reach of children

ASSEMBLY DETAILS:

STEP 1:

Open the zip at the bottom of sofa and take the hardware bag, and then check their quantity



STEP 2:

Fix the five wooden legs at the bottom of sofa

