


INSTRUCTION MANUAL



Rocking Chair

ORRC-002-GY/ORRC-002-BE



Questions? Comments?
Reach out to us for expert support!

✉ service@sundaleoutdoor.com

🌐 sundaleoutdoor.com

📞 (626) 899-5788

📍 2080 S Cucamonga Ave,
Ontario, CA 91761

Follow [sundaleoutdoor](http://sundaleoutdoor.com) on





READ & SAVE BELOW INSTRUCTIONS BEFORE ASSEMBLY

- Please separate and identify all parts, making sure that you have all of the parts listed.
- To avoid any scratch during assembly, please assemble on a soft mat or similar.
- Please assemble step by step and follow the instructions.
- Washers must be used.
- Do not completely fasten each screw and nut until all the screws are properly fixed.

WARRANTY

- Thank you for purchasing our outdoor furniture, We are pleased to offer a one-year warranty on the quality of the product. This warranty covers any manufacturing defects or malfunctions that may occur within the first year of ownership.
- Exclusions: The warranty does not cover damages resulting from misuse , negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.

MAINTENANCE AND CARE

- Protect it from extreme weather by moving it to a covered area or using furniture covers.
- Avoid dragging heavy objects on the furniture to prevent damage.
- Regularly inspect for wear or damage and address any issues promptly.
- Check and tighten hardware connections periodically.
- Keep packaging until assembly is complete to avoid losing small parts.
- Use a damp cloth with warm soapy water or a suitable cleaning product to clean the furniture.
- Ensure proper drying after cleaning to prevent mold growth.


CALIFORNIA PROPOSITION 65

⚠ WARNING: This product can expose you to Carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to WWW.P65Warnings.ca.gov


PARTS

- Carefully unpack all components and verify that all necessary parts are included in the package before assembling. Assemble the furniture in the order specified to ensure proper alignment and installation.
- If any difficulty occurs during assembly, please contact our customer support.

PARTS



Upper Back Panel
A1x1



Lower Back Panel
A1x1



Front Support Leg
Bx1



Back Support Leg
Cx1



Rocking Leg
Fx2




Cushion
Gx1

HARDWARES



Bolt M6*18
Dx13



Bolt M8*45
Ex4



Nut
Hx13

TOOL



Allen Wrench



Open-end Wrench




1PERSON
ASSEMBLY



UP TO 10 MIN.
ASSEMBLY



ASSEMBLY

Note: Do not fully tighten screws, tighten the screws only after all components are installed.



1


- Attach the Upper Back Panel[A] to the Lower Back Panel[A1] using Bolt M6*18[D] & Nut[H]
- Install the Front Support Leg[B] to the Lower Back Panel[A1] with the Bolt M6*18[D] & Nut[H]



2

- Attach the Back Support Leg[C] to the Lower Back Panel[A1] with the Bolt M6*18[D] & Nut[H]






3

Attach the Rocking Legs[F] to the the Front Support Leg[B] and the Back Support Leg[C] using Bolt M8*45[E]

F x2 **E** x4



4

Put the Cushion[G]

G x1

QUESTION ABOUT OUR PRODUCT? WE'RE HERE TO HELP.

————— Contact us at: service@sundaleoutdoor.com —————