



# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


## BASIC ASSEMBLY TECHNIQUES




Before attaching each of the screws, make sure that the **smaller lock washer is between** the larger washer and the head of the screw.




Position each part correctly and insert all screws into their respective holes. Then, **hand-tight and leave room for later adjustment. Do not use tool.**




Make sure the furniture rests on a **flat and level surface** with each leg evenly touching the ground.



Some furniture come with optional **height adjustment knobs** underneath each leg. Turn counter-clockwise or clockwise to raise and lower each leg.



Finally, make sure all parts are properly aligned then use the included **hex key** to completely tighten the screws. Your furniture is now ready for use.




Store the hex key for later maintenance. Tighten the screws again **after two (2) weeks**, and then at least **once every six (6) months** after that.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE SCREWS MAY LOOSEN OVER TIME AND CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS CAN LEAD TO COLLAPSE AND CAN CAUSE SERIOUS INJURY.**



**FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT TO INJURY AND/OR PROPERTY DAMAGE.**

# ASSEMBLY INSTRUCTION



## ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being relatively difficult). For some products, two persons are recommended.

EASY




DIFFICULT


















\*2 persons recommended

**Do not tighten screws until completely assembled.**


# PARTS IDENTIFICATION



**Do not tighten screws until completely assembled.**


PARTS IDENTIFICATION				HARDWARE LIST			
NO	Part	Sketch	Quantity	NO	Shape	Specification	Quantity
1#		LONG SHELF	3PCS	A		WOOD SCREW Ø7x48	32PCS
2#		SHORT SHELF	4PCS	B		CAMLOCK SCREW L29	20PCS
3#		LEANING PARTITIONAL PANEL	4PCS	C		CAMLOCK    Ø15	20PCS
4#		LEFT SIDE PANEL	1PC	D		DOWEL    Ø8x25	26PCS
5#		RIGHT SIDE PANEL	1PC	E		ANTI-TIP HARDWARE	1PC
6#		TOP PANEL	1PC	F		SELF-TAPPING SCREW    Ø4x25	1PC
7#		BASE	1PC	G		WALL SCREW Ø5x40	1PC
				H		PLASTIC PLUG Ø8x40	1PC
				I		STICKER    Ø20	14PCS
				J		GLUE	1PC

## STEP 1.




**Do not tighten screws until completely assembled.**

## STEP 2.




## STEP 3.




**Do not tighten screws until completely assembled.**

## STEP 4.




## STEP 5.



**Do not tighten screws until completely assembled.**

## STEP 6.



**Do not tighten screws until completely assembled.**