


ASSEMBLY INSTRUCTION



NOTES:


























- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:


- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.

1

PARTS LIST


A	B	C	O	P	Q	R	S				
											
2PCS	1PCS	1PCS	1PCS	4PCS	6PCS	2PCS	2PCS				
T	U	V	W	X	a	c	d	e	f	g	t
											
2PCS	2PCS	2PCS	4PCS	1PCS	1/4*85 4PCS	1/4*45 4PCS	1/4*37 2PCS	1/4*30 8PCS	1/4*21 4PCS	1/4*19 8PCS	4PCS
u	v	w	x	y							
											
1/4 4PCS	1/4 8PCS	1/4 2PCS	1/4 2PCS	1PCS							

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED




3

3




4




4

5




6




5


7



8



6



Warranty Information:

We warranty this product to be free from defects in materials. This warranty covers five years from the date of original purchase. Please contact us .