

ASSEMBLY INSTRUCTION COUNTER HEIGHT CHAIR

IMPORTANT SAFETY CONSTRUCTION


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment. Please read all instruction carefully before assembling. For your safety, assembly by two people is recommended.

PARTS INCLUDED:

- (1) Chair Back (a)
- (1) Complete Seat (b)
- (2) Front Leg (c)
- (1) Left facing Side Stretcher (d)
- (1) Right facing Side Stretcher (e)
- (1) Front facing Side Stretcher (f)

HARDWARE ENCLOSED:


- A 4x  Ø8
- B 4x  Ø6 x 75mm
- C 3x  Ø6 x 45mm
- D 11x  Ø8 x 13mm
- E 11x  Ø8 x 19mm
- F 1x 
- G 1x 
- H 6x  Ø4 x 38mm



ASSEMBLY INSTRUCTIONS

STEP 1:

- Carefully lay Chair Back flat on a smooth flat surface to prevent scratches.
- Affix Complete Seat to Chair Back by inserting a Flat Washer (E), Lock Washer (D) with Short Bolt (C) into each of the hole on the back rail of the seat, and Long Bolt (B) into each of 2 holes in the Complete Seat corners. (See Detail A & B).
- Tighten Screws with provided Allen Key (F) by turning clockwise until secure



STEP 2:

- Carefully turn Chair upside down and affix each Leg to the front corner of the Complete Seat. Place Flat Washer(E), Lock Washer (D) and Nut (A) on each leg bolt, tightening the Nut on each Leg using provided Key Wrench (F). Do not fully tighten the Nuts at this stage until all the parts are in position. (See Detail C)
- Insert two side stretchers between the front legs and the rear legs (Note the right side and the left stretcher). Insert the front stretcher between the front legs and fasten with the wood screws with a Phillips head screwdriver. (See detail D)
- Be sure to tighten all bolts and nuts before using the chair.

NOTES:

The use of power tools for assembly is not recommended. Power tools can damage hardware or split wood.