





ASSEMBLY INSTRUCTION


SOFA

A Lsf Sofa  1 PC	B Rsf Sofa  1 PC	C Lsf Arm  1 PC	D Rsf Arm  1 PC
E Back Cushion  2 PCS	F Wooden Leg  4 PCS	G Middle Leg  2 PCS	H Bolt M6 x 20mm  16 PCS
I Bolt M6 x 25mm  4 PCS	J Bolt M8 x 40mm  2 PCS	K Bolt M6 x 60mm  2 PCS	L Flat Washer Ø22mm  4 PCS
M Flat Washer Ø15mm  4 PCS	N Allen Key M8 x 35mm  1 PC		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Attach Lsf Sofa (A) to Lsf Arm (C) and Rsf Sofa (B) to Rsf Arm (D) by using brackets as shown. Make sure brackets are secured in position.




- 2** Attach Rsf Sofa (B) to Lsf Sofa (A) by using Bolt (J), Flat Washer (L) and Allen Key (N). Insert Bolt (K) and Flat Washer (L) into the pre-drilled holes of Lsf Sofa (A), Rsf Sofa (B), Lsf Arm (C) and Rsf Arm (D) and tighten them.



- 3** Attach Wooden Leg (F) to Lsf Arm (C) and Rsf Arm (D) by using Bolt (H) and Allen Key (N). Then attach Middle Leg (G) to Lsf Sofa (A) and Rsf Sofa (B) by using Bolt (I), Flat Washer (M) and Allen Key (N).



4 Put Back Cushion (E) on Lsf Sofa (A) and Rsf Sofa (B).



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.