



INSTRUCTION



BBK050



NOTICE










Before You Start

General Security Warning


Caution: The Product is not suitable for the children under 3 years
Danger: Lack of attachment may cause a risk of tipping.

 **WARNING:**
Product must be assembled by an adult. Keep small parts necessary for assembly out of children's reach.


  **WARNING:**
CHOKING HAZARD-Small parts.
Not for children under 3 years.

-  Please read all instructions carefully.
-  Please keep the instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near the area where they will be placed in use, to avoid unnecessarily moving the product.
-  Always place the product on a flat, steady, and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard


Parts and Hardware List




① x2




② x5




③ x2




④ x2




⑤ x3




⑥ x4




⑦ x1




⑧ x1




⑨ x2




⑩ x2




⑪ x2




⑫ x2



⑬ x2




⑭ x1




⑮ x2

Parts and Hardware List




①⑥ x1




①⑦ x1




①⑧ x5




①⑨ x2



②⑦ x1



②① x6



②② x1



②③ x1



6 * 40
A x22



4.2 * 60
B x38



6 * 30
C x18



4.2 * 30
D x16



6 * 35
E x4



3 * 10
F x20



4.2 * 25
H x10



L x2




K x2





G x3







STEP 1





	
4.2*60	6 * 30
B x10	C x6

STEP 2






		
6 * 40	4.2 * 60	6 * 30
A x 10	B x 8	C x 8

STEP 3






STEP 4





	
4.2*60	6 * 30
B x12	C x4

STEP 5






	
4.2*60	4.2*30
B x8	D x4

STEP 6





STEP 7




	
3 * 1	L x 2
F x 12	

STEP 8





STEP 9





4.2*25
H x10


STEP 10




STEP 11



STEP 12




STEP 13



STEP 14


First Play Mode




lock the buckle! !

STEP 15


Second Play Mode



Step1 unlock the buckle



Step2 fold the top area



Step3 another play mode

