



ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- part # - Left chaise
- part # - Armless sofa
- part # - Right chaise
- part # - Pillow
- part # - Middle leg
- part # - Chrome leg
- part # - Gold leg

Do not assemble if any of the following Hardware parts are missing:


- part # - Allen wrench
- part # - Bolt M8*25mm
- part # - Washer M8*16mm

2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included

- ① Left chaise
1pc




- ② Armless sofa
1pc




- ③ Right chaise
1pc




- ④ Pillow
2pcs




- ⑤ Middle leg
3pcs



- ⑥ Chrome leg
12pcs



- ⑦ Gold leg
12pcs



+ Hardware Included

- A** Allen wrench
1 pc



- B** Bolt M8*25mm
24pcs



- C** Washer M8*16mm
24 pcs



ASSEMBLY INSTRUCTIONS

