
Assembly Instructions




ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY ⬢⬢⬢⬢⬡ DIFFICULT

Tools Required For Assembly:

Allen Wrench  (Included)

Phillips Screwdriver  (Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST,CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.
PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches . Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE.THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Heardboard (Left)




#2 x 1pc
Heardboard (Right)




#3 x 2pcs
Lower Front Side Rail




#4 x 2pcs
Upper Front Side Rail




#5 x 4pcs
Back/Front Guardrail



#6 x 2pcs
Guardrail




#7 x 1pc
Center Support




#8 x 2pcs
Support Leg 320x40x40mm


Hardware List




#A x 24pcs
Bolt 1/4" x 3-1/8"




#B x 24pcs
Barrel Nut 1/4" x 1/2"




#C x 6pcs
Bolt 1/4" x 1-3/16"




#E x 16pcs
Wood Dowel 7/16" x 1-9/16"




#F x 28pcs
Screw 3/16" x 1-3/16"



#G x 2pcs
Screw 3/16" x 1-9/16"




#H x 1pc
Allen Wrench 4mm




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#9 x 1Set (10pcs)
Full Slat Kit




#10 x 1Set (10pcs)
Full Slat Kit







#A x 24pcs
#B x 24pcs
#E x 16pcs

1) Attach 2 dowels (#E) to each end of guardrails (#5), then insert barrel nuts (#B) to the side holes of the guardrails (#5). Align guardrails (#5) to the top holes of the headboards (#1,2). Secure by attaching bolts (#A) onto barrel nuts (#B) of the guardrails (#5).





3) Insert barrel nuts (#B) to the side holes of the lower side rails (#3). Align the side rails (#3) to the lower holes of the headboards (#1,2). Secure by attaching bolts (#A) to the barrel nuts (#B) of the side rails (#3).





2) Insert barrel nuts (#B) to the side holes of the side rails (#4). Align upper side rails (#4) to the top holes of the headboards (#1). Secure by attaching bolts (#A) onto barrel nuts (#B) of the side rails (#4).



#C x 6pcs

Align guardrail supports (#6) to the center holes of the upper guardrails, then secure by using bolts (#C).









Align center slat support (#7) to the center of the upper bunk, then secure by using screws (#F).

#F x 2pcs









Align slat support legs (#8) to the holes of the slat kit (#10). Secure by using screws (#G).

#G x 2pcs










#F x 26pcs

Align slat kit (#9) to the upper bunk, then secure onto side rails by using screws (#F).






Align slat kit (#10) to the lower bunk, then secure onto side rails by using screws (#F).







Safety Warnings for Bunk Beds

1. Read and follow the information on the WARNINGS shown on the end structure of the upper bunk and on the carton.
2. Do not remove warning label from the bed.
3. Keep these instructions for future reference.
4. Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.

   IMPORTANT: **Must use Bunkie mattress.** The proper sizes for the **UPPER TWIN-SIZE** Bunkie mattress should be 74" - 75" long and 37½" - 38½" wide with no more than 8" thickness.
   Must use Bunkies mattress. The proper sizes for the lower twin - size Bunkie mattress should be 74" - 75" long and 38½" wide with no more than 8" thickness.
5. Surface of mattress must be at least 5 inches (127 mm) **BELOW** the upper edge of guardrails.
6. The **MAXIMUM** weight capacity for the upper bunk is not to exceed 150 lbs
7. Do not allow children under 6 years of age to use the upper bunk.
8. Periodically check and ensure that the guardrails, ladder, other components are in their proper position, free from damage, and that all connectors are tightened and secured.
9. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
10. Always use the ladder for entering or leaving the upper bunk.
11. Do not use substitute parts.
12. Use of a nightlight may provide added safety precaution for a person using the upper bunk.
13. Always use the guardrails on both sides of the upper bunk
14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.
15. The use of water or sleep flotation mattresses is prohibited.
16. No more than one person is allowed on the upper bunk at all time



WARNING:
STRANGULATION HAZARD

Never attach or hang objects to any part of the bunk bed that are not designed for use with the bed. Objects such as hanger, hook, belt, bag, rope, string, etc. Should not be used on or around the bunk bed.