



# Assembly Manual

## Dining Chair




Please read this manual carefully before any operation and keep it properly for future use.


## Assembly-note:




- ① Put a protective mat on the ground and handle the product with care.




- ② Two people are preferred.



- ③ Contact us if you have any confusions





Exploded  
diagram:



| NO. | Name             | PCS |
|-----|------------------|-----|
| 1   | Chair Back       | 1   |
| 2   | Front Leg        | 1   |
| 3   | Side Stretcher L | 1   |
| 4   | Side Stretcher R | 1   |
| 5   | Seat             | 1   |

## Accessory list:


|                                                                                   |     |                                                                                   |   |                                                                                     |     |
|-----------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------|---|-------------------------------------------------------------------------------------|-----|
| <b>A</b>                                                                          |     | <b>B</b>                                                                          |   | <b>C</b>                                                                            |     |
|  |     |  |   |  |     |
| Bolt                                                                              | 8+1 | Allen wrench                                                                      | 1 | Screw                                                                               | 8+1 |

|                                                                                   |     |                                                                                   |     |                                                                                     |     |
|-----------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------|-----|-------------------------------------------------------------------------------------|-----|
| <b>D</b>                                                                          |     | <b>E</b>                                                                          |     | <b>F</b>                                                                            |     |
|  |     |  |     |  |     |
| Moon-shaped gasket                                                                | 8+1 | Gaske                                                                             | 8+1 | Spring gasket                                                                       | 8+1 |




|                                                                                     |     |                                                                                     |      |                                                                                       |   |
|-------------------------------------------------------------------------------------|-----|-------------------------------------------------------------------------------------|------|---------------------------------------------------------------------------------------|---|
| <b>G</b>                                                                            |     | <b>H</b>                                                                            |      | <b>I</b>                                                                              |   |
|  |     |  |      |  |   |
| Nut                                                                                 | 8+1 | Wood plug                                                                           | 16+2 | Spanner                                                                               | 1 |

Insert the Screw(C) and into the Chair Back(1) and Front legs(2) as shown.  
Insert the Wood plug(H) into the Left Stretcher(3) and Right Stretcher(4) as shown.  
**Please Fully tighten the Screw.**

1



**Tighten**





**(C)** (x4)

**(H)** (x8)

Insert the Left Stretcher(3) and Right Stretcher(4) into Chair Back(1).  
Attach Left Stretcher(3) and Right Stretcher(4)to Chair Back(1) using Gasket(D,E ,  
F,G ) with Spanner(I).

# 2



(D)



(E)



(F)







(G)





Insert Front Leg(2) onto the Left Stretchers and Side Right as shown.  
Attach Front Legs(2) to Side Stretchers using Gasket(D,E,F,G ) with Spanner(I).

3



Attach Frame and Seat cushion using Bolts( A) with Allen Key( B).  
**And then Fully tighten all of the Screw.(Include step 2 and step 3)**

4




A   
(x4)

---


Place the Dining Chair on a Level Surface to check for wobbles.  
If it wobbles, the adjustable foot pads at the bottom of the front legs can be adjusted.

---

5



Done



## **Warning**

- Please keep the product away from children while assembling.
- Do not let children play or jump on the product.
- Do not stand on the item or use as a step ladder.
- Prior to use, please check to see if there's any loosening screw or part.
- Make sure that each screw and part is correctly installed and securely fastened.

## **Care and Maintenance**

- Use a soft clean cloth that will not scratch the surface when dusting
- There's no need to use furniture polish.If you need, test it first in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Gently blot the spill with a soft clean cloth to avoid rubbing.

## **Further advice about the furniture care**

- It is best to keep your furniture in a climate-controlled environment.
- Extreme temperatures and humidity changes can cause fading.warping, shrinking and spitting of wood.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Proper maintenance and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.  
Periodically(every 90 days) make sure the screws are fully tightened.