


ASSEMBLY INSTRUCTIONS

BATH VANITY-CABINET






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not included)



(Not included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY







Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions

	Diagram A Insert Cam Bolt into hole as shown in diagram A.
	Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
 Connect the panels together.	
 ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.	
 To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>	


Detail View



Identifying the Hardware-Identify the hardware using the illustrations below.


Part Lists

1




Top Frame - 1pc

2




Side Panel (L) - 1pc

3




Side Panel (R) - 1pc

4




Top Front Crossbar - 1pc

5




Mid Front Crossbar - 1pc

6




Bottom Front Crossbar - 1pc

7




Bottom Frame - 1pc

9




Top Rear Crossbar - 1pc

10




Bottom Rear Crossbar - 1pc

11




Flip Drawer Face - 1pc

14




Flip Drawer Rear Panel - 1pc

15




Drawer Face - 1pc

16



Drawer Side Panel (L) - 1pc


17



Drawer Side Panel (R) - 1pc


Part Lists

18




Drawer Rear Panel - 1pc

19
















Drawer Bottom Panel - 1pc




Sink - 1pc

Hardware Lists

A  Ø8*30mm Wood dowel (24pcs)	B  Ø6*32mm Three in one bolts (14pcs)	C  Ø14.5*9.5mm Three in one locks (14pcs)
D  Ø13xØ1/4*40mm Hex-Head bolt (4pcs)	E  Hinge (2pcs)	F  Ø13xØ1/4*30mm Hex-Head bolt (15pcs)
G  K4mm Allen key (1pc)	H  Ø6xØ3.5*15mm Flat head screw (12pcs)	I  The Brass Hinge (L) (1pc)
J  Handle(2pcs)	K  Ø5/32*35mm Handle screw (2pcs)	L  Ø10x10mm Plastic Canopy (4pcs)
M  Ø8xØ4*50mm Round head screw (4pcs)	N  Anti fall Hardware (2sets)	O  Ø6xØ3*12mm Flat head screw (4pcs)
8  Leg (4pcs)	12  Flip Drawer Side Panel (L) - 1pc	13  Flip Drawer Side Panel (R) - 1pc


STEP: 1




B



6PCS



STEP: 2



C




6PCS

A




14PCS

F




4PCS

STEP: 3




F




6PCS

A




2PCS

STEP: 4




D




4PCS

STEP: 5




F






5PCS




A



2PCS

STEP: 6



I 	B 
1 PC	4PCS
O 	E 
2PCS	2PCS
J 	H 
1PC	4PCS
K 	C 
1PC	4PCS
A 	
6PCS	

STEP: 7

H




8PCS


O




2PCS




Use the screws to adjust up or down




Use the screws to permanent







Use the screws to adjust left or right



Use the screws to adjust in or out






STEP: 8




C 4PCS	L 4PCS	B 4PCS
	M 4PCS	J 1PC
		K 1PC

STEP: 9




STEP: 10

N




2SETS




STEP: 11

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.


STEP: 12



Adjustable Leveler



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

