

User Manual

Arched Floor Lamp BP-F009B

Introduction

Thank you for choosing our floor lamp. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact us with your order number and details.


Package Contents

- LED Bulb x1
- Remote control x1
- Lamp base x1
- User Manual x1
- Glass Lampshade x1
- Iron Pipes x6


Specification

LAMP	
Material	Metal+Rattan
POWER	MAX 60W
Input Voltage	AC120V 60HZ
Size	W 9.45" X 63.35"
Bulb	
Power	MAX 7W
LUMINOUS FLUX	800LM
DIMMABLE	10%-100%
Color temperature	3000K-6000K
Lifespan	30,000H
Remote Distance	MAX 49.2 ft
Input Voltage	AC120V 60HZ

Product Structure



Installation



Carefully remove all parts from the box and remove all plastic coverings

Step ①-②: Use a wrench to secure the screws to the base.

Step ③-⑧: Insert all the poles sequentially through the screws, following the image on the left.

Step ⑨: Slide the lampshade onto the base.

Step ⑩: Attach the screw ring to the bulb base through the bottom of the shade (unscrew it from the base first).

Step ⑪: Screw the E26 bulb into the lamp base.

Usage





There are two ways to control : Foot switch control/Remote control

Foot switch ON/ OFF



Remote Control




-  Short press for turning on/off.
-  Short press for 1 hour timer, will be released once pressed any other buttons.
-  Short/long press to enhance the brightness as you like.
-  Short/long press to change three color temperature from 3000 - 6000 K step by step or step-less.

When can you use the remote control?

One intelligent bulb is included in the package. You may use regular bulb to replace the intelligent bulb if you prefer that. Please note that regular bulb cannot match the remote control. Need to repair the remote control and bulb if you replace one of them. Please check the repair method below. Foot switch is the prerequisite for remote control. Make sure you have turned on the lamp with the foot switch when you are using the remote.

How to Repair the Remote Control and the Bulbs if the Remote is not Working?


- 1, Turn off the lamp with the foot switch firstly
- 2, Long press  .
- 3, Keep on pressing the button and turn on the lamp with the foot switch.
- 4, The lamp will flash for two times means repair is done.

When can you use the remote control?

A 9w 800Lumens intelligent bulb is included in the package. You may use regular bulb to replace the intelligent bulb if you prefer that. Please note that regular bulb cannot match the remote control. Need to repair the remote control and bulb if you replace one of them. Please check the repair method below.

Foot switch is the prerequisite for remote control. Make sure you have turned on the lamp with the foot switch when you use the remote for turning on/off, changing the CCT, modes and timer. Remote control cannot be used if foot switch is turning off status.

How to repair the remote control and the bulb if the remote is not working?

Long press the '

Product Care

- Please do not bend violently the lamp head to avoid damage when adjusting the angle of the lamp.
- Please read the user manual before use.
- Suggest indoor use . It is non waterproof .Do not use this product in humid environments or at high temperatures.
- Cut off the power when cleaning it or not using it.
- Do not use it exceed the voltage , the proper voltage for US is AC110- 120V.60Hz.
- Please stop use it if there is any defective issues found in the product.

Guarantee

our standing floor lamp is backed by 12MONTHS product warranty. For questions ,assistance , or support , please contact the Customer Service with your order number and product model number. We will send you future information about the return or the exchange.

