




**maze**

## ASCOT 4 SEAT ROUND DINING SET

Assembly Instructions for the Dining Table



**IMPORTANT-RETAIN FOR FUTURE REFERENCE**



## WARNINGS

- For domestic and outdoor use only.
- We suggest you retain these instructions for future reference.
- Keep fittings out of children's reach and keep children well away from construction area.
- Periodically check all fittings and re-tighten as necessary.
- Do not sit or stand on your table.
- Do not stand on your chair, sofa or stool.
- This product should only be used on firm, level ground. Make sure the legs remain in contact with the ground.
- Ensure any safety locks are correctly located and locked in place for any mechanisms before use.
- Keep hands away from folding mechanisms to prevent possible entrapment or injury.
- Any folding mechanisms should only be used by competent adults.
- The glass used in this product is toughened and complies with BS EN 12150-1:2009

## DO'S

- We suggest you spend a short time reading through this leaflet before you start.
- When you are ready to start, make sure that you have the right tools and plenty of space.
- Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.
- Carefully check that you have all the parts before starting assembly.
- Please retain the assembly tools. You will need them in the future to re-tighten the bolts, or if you want to dismantle the furniture for storage.
- Please make sure that the product is clean and dry before putting it into storage.
- We recommend the use of furniture covers to protect your furniture when not in use. During severe weather conditions, please move your furniture inside. (eg. High Winds)
- To clean your items, please use mild detergent in warm water. Rinse with clean water and dry thoroughly. Do not use abrasive cleaners, strong detergents, bleach, acid or solvents on the frame parts.
- When cleaning glass panels, use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these substances can scratch glass panels.

## DON'TS


- Do not stand on your chairs, sofas or stools.
- Do not sit on the arms of your chair or sofa.
- When moving furniture never drag the pieces across the floor, as this will cause damage to the joints.
- Do not use silicone based furniture polish.
- If the glass is chipped or broken, stop using the product and consult our customer service team.
- Do not place very hot or very cold items on the glass surface, unless adequately thick table mats are used to prevent such items from coming into contact with the glass.
- Do not use glass as a chopping surface.
- Do not strike the glass with hard or pointed items.

## ASSEMBLY


Two persons to assemble the unit and lift the unit into position.

## MISSING PARTS

If you are missing any fixtures or fittings for your product please contact our customer service team.




Components supplied. Please use this guide if you require replacement parts.

| Ref | Dimensions | Visual                                                                              | Qty |
|-----|------------|-------------------------------------------------------------------------------------|-----|
| 1   | Ø120x0.8cm |  | 1   |
| 2   | Ø121x6cm   |  | 1   |
| 3   | 72X71cm    |  | 2   |
| 4   | 56X38cm    |  | 2   |

Fixtures and fittings supplied(actual size)

| Ref | Dimensions | Qty |
|-----|------------|-----|
| A   | Ø13x5mm    | 12  |
| B   | Ø16x1mm    | 12  |
| C   | Ø4X66mm    | 1   |
| D   | M6x20mm    | 12  |



**IMPORTANT-RETAIN FOR FUTURE REFERENCE**



# ASCOT 4 SEAT ROUND DINING SET

## Assembly Instructions for Dining Table

- 1** Unbox your dining table to begin the assembly process.

Lay the table top (2) upside down on a flat surface.

**Ax4**  $\varnothing 13 \times 5.0\text{mm}$



**Dx4** M6 x 20mm



**Bx4**  $\varnothing 16 \times 1.0\text{mm}$




**Cx1**  $\varnothing 4 \times 66\text{mm}$



Using your 2x leg side panels (3) align them up with the screw holes

Use a washer, bolt and nut to secure the panels to the table top. Tighten the bolts using the allen key.

(Do not fully tighten until you have completed the next step)



- 2** Now secure your other 2x other side panels (4) to the leg side panels you have just attached.

Use a washer, bolt and nut to secure the panels to the leg side panels.

**Ax8**  $\varnothing 13 \times 5.0\text{mm}$



**Dx8** M6 x 20mm



**Bx8**  $\varnothing 16 \times 1.0\text{mm}$




**Cx1**  $\varnothing 4 \times 66\text{mm}$




Tighten the bolts using the allen key.

You can now fully tighten all the bolts and nuts to make sure the panels are secure and stable.



- 3** Turn your table over and now place your glass (1) onto your table top.

We recommend placing your glass on top using two persons for safety.



**IMPORTANT-RETAIN FOR FUTURE REFERENCE**