


21*29. 2cm

3 Reindeers Assembly Instructions

1. Diagram of Parts


Remove all components from the box and lay flat on the floor.

- Buck: 2 Antlers, 2 Ears, Head, Body, 4 Legs, Tail
- Doe: 2 Ears, Head, Body, 4 Legs, Tail
- Fawn: 2 Ears, Head, Body, 4 Legs, Tail
- 12 Ground Stakes
- 36 Zip Ties




2. Assembling the Buck

- (A) Insert the connecting rods on the top of the Legs into the sides of the Body. Then, fasten with Zip Ties on each leg. Insert the two hook ends of the Metal Bars into the metal nut on the legs to stabilize the Buck.
- (B) Insert the two connecting rods on the front neck and back neck of the Buck Head into the Buck Body. Then, fasten with Zip Ties.
- (C) Attach the Antlers and the Ears on top of the Buck Head. Insert the Tail into the back of the Body.




3. Assembling the Doe

- (A) Insert the connecting rods on the top of the Legs into the sides of the Body. Then, fasten with Zip Ties on each leg. Insert the two hook ends of the Metal Bars into the metal nut on the legs to stabilize the Deer.
- (B) Attach the hook on the back neck of the Doe into the Doe Body. Then, fasten the front neck of the Doe with Zip Ties.
- (C) Attach the Ears on top of the Deer Head. Insert the Tail into the back of the Body.



4. Assembling the Fawn

- (A) Insert the connecting rods on the top of the Legs into the sides of the Body. Then, fasten with Zip Ties on each leg. Insert the two hook ends of the Metal Bars into the metal nut on the legs to stabilize the Fawn.
- (B) Insert the two connecting rods on the front neck and back neck of the Fawn Head into the Fawn Body. Then, fasten with Zip Ties.
- (C) Attach the Ears on top of the Fawn Head. Insert the Tail into the back of the Body.



5. Securing the Reindeers to the ground by placing the Ground Stakes over the holes on each leg, then into the ground.

6. Connecting the Wire Cord with the cable from the bottom of each Deer. Then, plug in the Wire Cord to electric outlet.



Instruction Manual
For indoor and outdoor use
Retain carton for storage purposes

3 Synthetic Rattan LED Reindeers, Buck, Doe & Fawn

IMPORTANT: Please read this manual carefully before assembly and save it for reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

a) READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- (b) Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- (c) This seasonal-use product is not intended for permanent installation or use.
- (d) Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- (e) Do not secure wiring of the product with staples or nails, or place on sharp hooks or nails.
- (f) Do not let lamps rest on the supply cord or any wire.
- (g) Unplug the products when leaving the house, or when retiring for the night, or if left unattended.
- (h) This is an electric product -- not a toy! To avoid risk of fire, burns, personal injury, and electric shock, it should not be played with or placed where small children can reach it.
- (i) Do not use this product for anything other than its intended use.
- (j) Do not hang ornaments or other objects from cords, wire, or light strings.
- (k) Do not close doors or windows on the product or extension cord as this may damage the wire installation.
- (l) Do not cover the product with cloth, paper, or any material not part of the product when used.
- (m) This product is equipped with push-in type lamps. Do not twist lamps.
- (n) Read and follow all instructions that are on the product or provided with the product.

SAVE THESE USE AND CARE INSTRUCTIONS

- (a) Before using or reusing, inspect the product carefully. Discard any product that has cut, damaged or frayed wire installation or cords, crack in the lamp holders or enclosures, loose connections, or exposed copper wire.
- (b) When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
- (e) When not in use, store neatly in a cool, dry location protected from sunlight.

WARNING: Risk of fire, personal injury and electric shock.

1. Make sure light set is not connected to power before starting.
2. Keep wires clear of being pinched or cut during assembly, installation, or use. Discard product with cut wire insulation.
3. Do not press or grasp bulbs during assembly or installation.
4. Watch for bulbs that may have broken if parts shifted in transit.
5. This product is not a toy, for adult use only. It should not be played with or placed where children can reach it.
6. Make sure stakes are clear of underground sprinkler, telephone, and power lines before starting.

7. Please read all instructions and warnings included with this product before using.

If lights do not work:

- a. Make sure there is power to the outlet and the product is plugged in.
- b. Make sure the cord is well connected to the adpater.
- c. If plugged into a GFCI outlet or GFCI-protected circuit, check the rest of the GFCI to make sure it did not trip. Discard product if GFCI repeatedly trips.

JOYIN US CORP
TEMPE, AZ, 85284, USA
MADE IN CHINA