

# Introduction

Thanks for choosing Bistro Set. Our success depends on happy customers and we hope you will be pleased with your purchase. If there are missing part or broken parts, or if you need futher assistance, please contact customer service online.


#### \*Notice:

- 1. 50% Tighten before fixing all screws.
- 2. Place the item on a flat ground to adjust and make sure it remains stable
- 3. Tighten up all screws with tools gradually
- 4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again


## **Table Part List:**

No.	Picture	Parts	Qty	No.	Picture	Parts	Qty	
A	0	Table Top	1	н	9	Spring Washer (8MM)	8	D A
В	)	Table leg	4	1	٩	Nut (8MM)	8	
С	0	Leg Support	1	J	0	Flat Washer (8MM)	8	E
D		Cover	1	к	Ð	Spring Washer (8MM)	8	† c
E		Ice Bucket	1	L	٩	Nut (8MM)	8	В
F	(*************************************	Stud M8*30	8	м	2=3	Wrench	1	***
G	(6)	Flat Washer (8MM)	8	N	<del>(</del> (100000)	Stud M8*35	8	

### **Assembly Instructions**




1.Unpack and place all parts on a clean soft surface.



2. Attach part B table legs to part A table top witheight part F studs,eight part G flat washers, eightpart H spring washers, and


eightpart I nuts.

DO NOT OVER TIGHTEN



3. Attach part C leg support to part B table legs with four part N studs, four part J flat washers, four part K spring washers, and four part L nuts.

#### DO NOT OVER TIGHTEN



4. Insert part E ice bucket into the middle of part A table top. Place part D cover on top of ice bucket.





- Flip table upright and adjust the preinstalled leveler until the table is level with the ground.
- 6. Securely tighten all nuts.

#### **Chair Part List:**


No.	Picture	Parts	Qty	No.	Picture	Parts	Qty	No.	Picture	Parts
F		Backrest	1	1	L	Right Arm	1	L	0	Washers(8mm)
									0	Spring washers(8mm)
									(1)	Nuts(8mm)
G		Chair Seat	1	J	T	Left Arm	1	м	<b>(</b>	Plastic cap(6mm)
н	V	Chair leg	4	к	0	Washers(6mm)	4	N	8	Bolts M6*35
					0	Spring washers(6mm)	4	o	~	Allen Wrench
					<b>(3)</b>	Nuts(6mm)	4	Р	300000)	Stud M8*30
į.	70 P		20 VB		· ·		57 98	Q	5=2	Wrench

#### **Assembly Instructions**





3.Attach part I right arm and part J left arm to part G chair seat with four part N bolts, four part K washers, spring washers, and nuts, and two part M plastic caps.



4.Use part Q wrench to attach part H chair legs to part G chair seat with two part L nuts ,washers,and spring washersper leg. DO NOT OVERTIGHTEN.



5.Flip chair upright and adjust the pre-installed levelers until the the chair is level with the ground.
6.Securely tighten all bolts, nuts, and screws.

Qty 10 10

10