










ASSEMBLY INSTRUCTIONS



packed in 3 cases


Carton	Disignation	Part		Hardware
L1	Backrest	#2		
L2	Seat frame	#1		
	Seat cushion	#5		
	Leg	#6		
ARM	Left arm	#3		
	Right arm	#4		

ASSEMBLY INSTRUCTIONS




PARTS

#1 1pc



SEAT FRAME

#2 1pc




BACKREST

#3 1pc




LEFT ARM

#4 1pc




RIGHT ARM

#5 2pcs



SEAT CUSHION

#6 4pcs



LEG

HARDWARE

#A 8 pcs



BOLT 1 -1/4" L

#B 1 pc



ALLEN KEY 4mm L

#C 8 pcs



FLAT WASHER 16mm

#D 8 pcs



SPRING WASHER


#E 16 pcs




Screw 40mm L

ASSEMBLY INSTRUCTIONS


STEP1:



STEP2:




STEP3:




ASSEMBLY INSTRUCTIONS


STEP4:



STEP5:



STEP6:



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✔ Keep this handy!


Please retain this instruction manual and any order-related information for future reference.

✔ Lift, don't drag!








To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

ASSEMBLY INSTRUCTIONS


SOFA



SOFA is packed in 3 cases


Carton	Disignation	Part	Hardware
S1	Backrest	#2 	
S2	Seat frame	#1 	#A #B #C #D #E
	Seat cushion	#5 	
	Leg	#6 	
	Support leg	#7 	
ARM	Left arm	#3 	
	Right arm	#4 	

ASSEMBLY INSTRUCTIONS




PARTS

#1 1pc



SEAT FRAME

#2 1pc




BACKREST

#3 1pc




LEFT ARM

#4 1pc




RIGHT ARM

#5 3pcs




SEAT CUSHION

#6 4pcs



LEG

#7 1pc



SUPPORT LEG

HARDWARE

#A 8 pcs



BOLT 1 -1/4" L

#B 1 pc



ALLEN KEY 4mm L

#C 8 pcs



FLAT WASHER 16mm

#D 8 pcs



SPRING WASHER


#E 16 pcs




Screw 40mm L

ASSEMBLY INSTRUCTIONS


STEP1:



STEP2:




STEP3:




ASSEMBLY INSTRUCTIONS


STEP 4:



STEP 5:



STEP 6:



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.