


17



18




F1

X 8




V2

X 8



WS3A

X 2



19




F1

X 8





V2

X 8



W3A

X 2






F1

X 8




V2

X 4






ULA

X 1





UR1

X 1







21








22



F1 X 28





F2 X 18

M16 X 2

M17 X 2

M18 X 2


24




F2

X 16




M16

X 2




M17

X 2



M18

X 2










25



F2 X 12

Tighten all screws



**F1****X 153****PK1****X 2****PK2****X 1****V3****X 153****PK3****X 3****PK4****X 7****PK9****X 1**

27



F1

X 1



V3

X 1




16

X 1



17

X 1



28



F1

X 2



V3

X 2

