











Please read these instructions and warranty information carefully before use and keep them properly for future reference.



OPERATING INSTRUCTIONS

Part List



 9 ×1 780×190×15mm	 2 ×1 527×105×15mm
 3 ×1 527×105×15mm	 4 ×1 803×110×15mm
 5 ×1 803×110×15mm	 6 ×1 570×479×3mm
 7 ×1 803×170×15mm	 8 ×1 803×170×15mm
 A ×2  B ×14  C ×14  D ×8	
 E ×10  F ×4  G ×4  H ×2  I ×8	

Assembly Instructions



12



34



56



78

