

Assembly Instructions

Accent Chair

Important safety instructions:

- Thanks for your purchasing this product, please read carefully instruction before assembly.


- For your safety and ease, assembly by two or more adults is recommended.

Keep instructions for future use.










Pre-assembly:

- Do not discard any content until assembly is complete to avoid accident tally discarding parts or hardware.


- Take out all parts and hardware from box and place them on a clean, soft and smooth surface.



Parts List


<p>Ax1</p> 	<p>Bx1</p> 	<p>Cx2</p> 	<p>Dx2</p> 
<p>CHAIR SEAT</p>	<p>CHAIR BACK</p>	<p>FRONT LEG</p>	<p>BACK LEG</p>
<p>Ex4</p> 			
<p>WASHER</p>			
<p>Fx1</p> 	<p>Gx1</p> 	<p>Hx1</p> 	<p>Ix1</p> 
<p>BOLTS(M8x50mm)</p>	<p>SPRING WASHER</p>	<p>WASHER</p>	<p>ALLEN WRENCH</p>

OVERVIEW:




Assembly Steps:


Step 1: Take out 2pcs **Front Leg(C)** and 2pcs **Back Leg(D)** From the bottom of the **Chair seat(A)**



Step 2: Clockwise rotate the four legs to assembly the **Front legs(C)** and **Back Legs(D)** to the **Chair Seat(A)**



Step 3: Turn the chair up and down, then insert the **Chair back(B)** into the **Chair Seat(A)**



Step 4: Turn the chair bottom up and assembly the **Chair back(B)** to the **Chair Seat(A)** with **Bolts(F)**&**Spring Washer(G)**&**Washer(H)**&**Allen Wrench(I)**. Then, turn the chair upright, your chair is ready for use.

Notice: If the chair wobbled, you can adjust the nails on the **Back Leg(C)** to make the chair flat.

