


Four door wardrobe






IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !

Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.


IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.


For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.


Board Identification




PARTS LIST




1




2




3




4




5




6




7




8




9



10




11




12


PARTS LIST




13




14




15




16 x2




17




18 x2




19 x2




20 x3




21 x3




22 x3




23 x3




24 x3



25 x3




26 x3




27 x 4


PARTS LIST




28




29




30 x2




31 x2




32




33 x2




34




35






36 x2














When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size




Tips:The number after "+" represents the spare hardware.





A x 85	B x 82	C x 47	D x 186
			
∅15 x 9.5 mm	∅7 x 40 mm	∅ 8 X 40 mm	∅3.5 x 14 mm

E x 11	F x 3	G x 16	H x 12
			
	∅7 x 40 mm	∅ 5 x 40 mm	∅ 4 x 25 mm





I x 6	J x 85	K x 6	L x 10
			
∅ 8 X 20 mm			∅ 15 mm


M x 2	O x 1	P x 78
		
M - 1 M - 2 M - 3 M - 4		∅ 4 x 12 mm


x 3	Q x 18	R x 16
		
400mm CL CR DL DR	∅ 4 x 35 mm	

N-1 x 12	N-2 x 10	S x 4	
			
			+2 SPARE BAG


1

B x 12	F x 3	E x 3	Q x 6	
				
Ø7 x 40 mm	Ø7 x 40 mm		Ø 4 x 35 mm	







x3





x3

2






A x 15	Q x 12	
		
Ø15 x 9.5 mm	Ø4 x 35 mm	











3


D x 18	DL x 3	DR x 3	B x 8	
				
Ø3.5 x 14 mm	400mm	400mm	Ø7 x 40 mm	






4


A x8	C x 16	G x 8	
			
Ø15 x 9.5 mm	Ø 8 X 40 mm	Ø 5 x 40 mm	






5











Screw M-2 can not lock too tight








6


B x 6	K x 2	D x 4	
 Ø7 x 40 mm		 Ø3.5 x 14 mm	











7


B x 12	CL x 3	D x16	K x 2	
				
Ø7 x 40 mm	400mm	Ø3.5 x 14 mm		








8

B x 10	CR x 3	D x16	K x 2	
				
Ø7 x 40 mm	400mm	Ø3.5 x 14 mm		























9


A x 12	B x 12	
		
Ø15 x 9.5mm	Ø7 x 40 mm	






10




A x28	C x 8	
		
Ø15 x 9.5 mm	Ø 8 X40 mm	







Kind reminder:The cabinet needs to be assembled on flat ground!


11


A x 8	C x 16	G x 8	
			
Ø15 x 9.5 mm	Ø 8 X40 mm	Ø 5 X40 mm	







12








Attention: The direction of the lead holes should face upwards!






Remove the film before pasting, but do not remove the double-sided sticky tape together!




13


A x14	C x 7	L x 10	
			
Ø15 x 9.5mm	Ø 8 X40 mm		

Attention: The direction of the lead holes should face upwards!





14


H x 12	I X 6	
		
Ø 4 x 25 mm	Ø 8 X 20 mm	



15

P x 78	R x 16	
 ∅ 4 x 12 mm		


Pay attention to the installation direction of the wardrobe backboard!




Notice:The upper and lower holes should correspond to a straight line!


16

M x 2




M-3 M-4






⚠ Warning: If you overturn the furniture, it may cause serious or fatal crushing injuries. We have a wall connection device attached, please use it to hold the furniture following these instructions.


1. Mark the corresponding hole positions where you want to place the furniture;
2. Use a impact drill to drill holes and pay attention to avoid wires and water pipes;
3. Knock the expansion pipes into the wall holes;
4. Place the furniture in the corresponding position and tighten the wall, Then lock the M-2 screw tightly.





17

S x 4



















18


N-1 x 4	N-2 x 10	E x 6	D x 28	
			 Ø3.5 x 14 mm	



19


N-1 x 8	E x 2	D x 16	
		 ⌀3.5 x 14 mm	






20


D x 88



Ø3.5 x 14 mm





Pay attention to installing the corresponding side panel on board 27 with N-1 or N-2 hinges!




21


J x85


Remove the protective film before use!
21
21
21
Cabinet Slide
Drawer Slide
J
Jx85
Stick the ring patch J on the lock holes





Adjust this screw to fine-tune the upper and lower positions of the door.






Adjust this screw to fine-tune the position under the door






Adjust this screw to fine-tune the left and right position of the door panel.



21

-LED lamp with effective remote control distance of 5 meters




1.Take out the remote control gasket

Remote control mode

OFF ON	In any state press these two keys to turn on/off the light strip.
	When light is on, press these two keys to reduce-or increase+brightness there are 10 brightness levels for adiustment.
R G B W	Press relevant keys to select particular colors
	Press this key to switch static colors There are 16 kinds for chosen.

APP PROGRAM USAGE




Scan two-dimensional code download APP

① Connect LED color strip and controller, power on controller

② Scan two-dimensional code download APP:

③ Start APP, search and connect controller

④ Enjoy the Bluetooth wireless control experience



Notes:
detailed operating instructions, enter the menu "Guide":

Product Paramters:
- Bluetooth: BLEV4.2
- Input Voltage:4.5~26V
- Working Temp:-25~75℃
- Size:43*22*11mm
- Weight:30g
- Max Power:144W(24V)

LED mobile phone Bluetooth

controllerProduct Features
- LED Bluetooth controller is directly via mobilephone control remote distance can reach 20m without the need to set up, easy to connect open the software within 5 seconds you can automatically connect the controller
- Flow the rhythm of the music changes
- Group control
- Brightness, speed addition and subtraction
- Maximum can be 10 meters RGB(W) strip
- The software shows that the text is based onthe language of the mobile phone set up automatic transformation of Chinese and English

Animation Effect:
- Colorful gradient
- All kinds of monchrome, double color gradient
- All kinds of monochrome, double color,colorfull flashing
- Colorful jump
- Follow the thythm of the music chagnes