















Please read these instructions and warranty information carefully before use and keep them properly for future reference.




OPERATING INSTRUCTIONS

Parts and Accesorrries





A 12pcs 	B 12pcs 	C 4pcs 	D 32pcs 
E 62pcs 	F 8pcs 	G 10pcs 	H 2pcs 
I 2pcs 	J 16pcs 	K 4pcs 4*25 	



1




2



3




4




A*8 B*8 C*2


A



B





5




A*4 B*4 C*2

7




6




D*4 K*4

X2



D*8 J*8 L*4

8



D*12 E*12

9

